



Leading Conversion Technology for Power Resilience

TSI MIPS - 120 VAC

MODULAR INVERTER POWER SYSTEM

User Manual

BEYOND THE INVERTER

THE NEW GENERATION OF POWER CONVERTERS

- **DUAL INPUT INVERTER**
Commercial Power as default source
- **AC BACKUP IN A DC ENVIRONMENT**
Leverage your existing DC infrastructure
- **ONE STOP SHOP**
Wide output power range
- **HARSHEST AC INPUT CONDITIONS**
Without compromising the quality of the AC output



Copyright © 2024. Construction electroniques & telecommunications S.A.
All rights reserved. The contents in document are subject to change without notice.
The products presented are protected by several international patents and trademarks.
Address: CE+T S.a, Rue du Charbonnage 12, B 4020 Wandre, Belgium
www.cet-power.com - info@cet-power.com

Version 7.7

Contact us:  www.cet-power.com | Follow us on social media:



Table of Contents

1. CE+T Power at a glance.....	6
2. Abbreviations	7
3. Warranty and Safety Conditions	8
3.1 Disclaimer	8
3.2 Technical care	8
3.3 Installation	9
3.3.1 Handling.....	9
3.3.2 Surge and Transients Protection	10
3.3.3 Other.....	10
3.4 Maintenance	10
3.5 Replacement and Dismantling.....	10
4. TSI Technology.....	11
4.1 EPC Mode	12
4.2 On-line Mode (REG Mode)	12
4.3 Safe Mode.....	12
4.4 Mix Mode & Walk-in Mode.....	12
5. Inverter Components.....	13
5.1 Inverter module	13
5.2 Sub-rack (Shelf)	13
6. Accessories	14
6.1 Monitoring - T2S-ETH.....	14
6.1.1 Parameters setting	14
6.1.2 System diagnostic and troubleshooting	14
6.1.3 Section Monitoring	14
6.2 Monitoring - Inview X	15
6.2.1 Inview X - Connections.....	15
6.2.2 Inview X and T2S-ETH Connection	16
6.3 Manual Bypass.....	17
6.3.1 EMBS	17
6.4 Surge Arresters	17
7. MIPS Design and Description	18
7.1 System Design	18
7.2 System Description	19
7.3 MIPS Single phase Configuration - 120 VAC.....	20
7.4 MIPS Single Phase Configuration - 240 VAC.....	21
7.5 MIPS Three Phase Configuration - 208 VAC	22
7.6 MIPS Module Based Current Ratings	23
8. System Installation.....	24
8.1 Site Preparation.....	24

8.1.1	Transformer and Generator Sizing	25
8.2	Packaging Information.....	25
8.3	Module packing.....	25
8.4	Anchoring the cabinet to the floor.....	26
8.5	Cabling.....	26
8.5.1	Tightening Torque	26
8.5.2	Cable Inlets	27
8.5.3	Grounding	27
8.5.4	AC Input and Output	28
8.5.5	DC Input.....	29
8.5.6	Signaling	34
8.6	Switching OFF MIPS System.....	35
9.	Human-Machine Interface.....	36
9.1	Inverter module	36
9.2	T2S-ETH.....	37
9.3	Graphical User Interface - Inview X.....	37
9.3.1	Inview X - LCD Interface	37
9.3.2	Inview X - LCD Menu Structure.....	38
9.3.3	Inview X - LED Indications	39
9.3.4	Inview X - Web UI	39
9.3.5	Software Overview	39
9.4	Inview X Software Verification and Configuration	40
9.5	Inview X - Inverter Connection.....	41
9.6	Accessing the T2S-ETH GUI via Inview X (software version 6.2.0 and above)	45
9.7	T2S - Web UI	46
9.8	Interface Areas	46
9.8.1	Banner	47
9.8.2	Main Area.....	47
9.8.3	Toolbar	48
10.	Unit - Inserting/removing/replacing	50
10.1	TSI Inverter Module	50
10.1.1	Removal.....	50
10.1.2	Inserting.....	50
10.2	T2S-ETH.....	51
10.2.1	Removal.....	51
10.2.2	Inserting.....	51
10.3	Inview X	52
10.4	Fan replacement	53
11.	Manual Bypass Operation	54
11.1	Pre-requisites.....	54
11.2	Manual Bypass Operation.....	54
11.2.1	Normal to Bypass, Engage MBP.....	54
11.2.2	Bypass to Normal, Disengage MBP.....	55

12. EMBS.....	55
13. Final Check.....	56
14. Commissioning	57
14.1 Check list.....	57
15. Trouble shooting	58
15.1 Trouble shooting.....	58
15.2 Defective modules.....	59
15.2.1 Replacing modules.....	59
15.2.2 Return defective T2S interface	59
15.2.3 Return defective shelf	59
15.2.4 Return defective modules.....	59
16. Service	60
17. Maintenance Task.....	61

Release Note:

Version	Release date (DD/MM/YYYY)	Modified page number	Modifications
7.0	19/02/2014	-	First release of the Manual
7.1	30/04/2014	16	System description illustration (AC in & AC out representation changed)
		23	Cabinet inlets illustration (AC in & AC out location changed)
		24	Earth grounding and Neutral grounding illustration
		36	MBP section updated with content
7.2	23/03/2015	6, 7, 11, 22, 32, 34, 36, and 39	Added additional information and updated the illustrations
7.3	20/04/2016	-	Amendment and correction
7.4	07/03/2018	-	Updated images and information
7.5	23/10/2020	-	New layout
7.6	15/05/2024	-	Replaced Catena with Inview X
7.7	27/05/2024	-	Removed 125 and 380 Vdc information

1. CE+T Power at a glance

CE+T Power is your trusted partner in **advanced power solutions** engineered to meet the demands of modern and dynamic industrial applications. With over 60 years of experience in power conversion technology, CE+T Power nurtures the industry with **innovative solutions designed for critical power backup and energy management**.

Our complete range of power solutions includes **modular inverters** (DC to AC), UPS (securing AC loads with batteries), and **multi-directional converters** (inverter, rectifier, and UPS all-in-one). Coupled with our state-of-the-art **monitoring solution**, you have a real energy blender to connect multiple sources of energy seamlessly!

Whether you require **robust backup power solutions**, **energy management solutions**, or a **combination of both**, CE+T Power delivers tailored solutions to meet your specific needs. Our products are **designed with integration in mind**, **ensuring seamless compatibility with other components of your system**. CE+T Power is committed to providing you with the expertise and resources needed to maximize the performance of your power systems.

Thank you for choosing CE+T Power as your partner in advanced power management. Let's power the future together.

2. Abbreviations

AC	Alternating current
CB	Circuit Breaker
DC	Direct current
DHCP	Dynamic Host Configuration Protocol
DSP	Digital Signal Processor
EMBS	External Maintenance Bypass Switch
EPC	Enhanced Power Conversion
ESD	Electro Static Discharge
ETH	Ethernet
G	Ground / Grounding
HTTP	HyperText Transfer Protocol
HTTPS	Secure HyperText Transfer Protocol
LAN	Local Access Network
MBP	Manual By-pass
MCB	Miniature Circuit Breaker
MCCB	Molded Case Circuit Breaker
MET	Main Earth Terminal
MIB	Management Information Base
N	Neutral
NTP	Network Time Protocol
NUA	Non-Urgent Alarm
PCB	Printed Circuit Board
PE	Protective Earth (also called Main Protective Conductor)
PPE	Personal Protective Equipment
PWR	Power
REG	Regular
SNMP	Simple Network Management Protocol
TCP/IP	Transmission Control Protocol/Internet Protocol
TRS	True Redundant Structure
TSI	Twin Sine Innovation
UA	Urgent Alarm
USB	Universal Serial Bus

3. Warranty and Safety Conditions*

WARNING:

The electronics in the power supply system are designed for an indoor, clean environment.

When installed in a dusty and/or corrosive environment, indoors, it is important to:

- Install an appropriate filter on the enclosure door, or on the room's air conditioning system. Installation of filters may result in derating of module.
- Keep the enclosure door closed during operation.
- Replace the filters on a regular basis.

Important Safety Instructions, Save These Instructions.

3.1 Disclaimer

- The manufacturer declines all responsibilities if equipment is not installed, used or operated according to the instructions herein by skilled technicians according to local regulations.
- Warranty does not apply if the product is not installed, used, or handled according to the instructions in the manual. Manufacturer may waive warranty if the system is not installed and commissioned by factory trained technician.
- EMBS handshake compatibility with CE+T equipment is only functional with inverter modules equipped with firmware version 208.4 or higher. Ensure all modules installed in paired equipment comply with this requirement.
- This equipment is shipped with a SHOCKWATCH monitor, which is present only on the crates and pallets. The warranty will be void if the SHOCKWATCH shows that the equipment was exposed to excessive force.

3.2 Technical care

- This electric equipment can only be repaired or maintained by a "qualified employee" with adequate training. Even personnel who are in charge of simple repairs or maintenance are required to have knowledge or experience related to electrical maintenance.
- Please follow the procedures contained in this Manual, and note all the "DANGER", "WARNING" AND "NOTICE" marks contained in this Manual. Warning labels must not be removed.
- Qualified employees are trained to recognize and avoid any dangers that might be present when working on or near exposed electrical parts.
- Qualified employees know how to lock out and tag out machines so the machines will not accidentally be turned on and injure employees working on them.
- Qualified employees are trained in OSHA and NFPA safety related work practices, and NFPA 70E Arc Flash Protection and PPE requirements.
- All operators are to be trained to perform the emergency shut-down procedure.
- Never wear metallic objects such as rings, watches, or bracelets during installation, service and maintenance of the product.

* These instructions are valid for most CE+T Products/Systems. Some points might however not be valid for the product described in this manual.

- Maximum operating ambient temperature is 40°C (104°F).
- Insulated tools must be used at all times when working with live systems.
- When handling the system/units pay attention to sharp edges.
- This product is suitable for use in a computer room.

3.3 Installation

- This product is intended to be installed only in restricted access areas as defined by UL60950 and in accordance with the National Electric Code, ANSI/NFPA 70, or equivalent agencies.
- The Inverter System may contain output over current protection in the form of circuit breakers. In addition to these circuit breakers, the user must observe the recommended UL listed upstream and downstream circuit breaker requirements as defined in this manual.
- Please use extreme caution when accessing circuits that may be at hazardous voltages or energy levels.
- The modular inverter rack is a dual input power supply. The complete system shall be wired in a way that both input and output leads can be de-energized when necessary.
- REG systems and EPC systems that have no AC input wired and connected can be seen as independent power sources. To comply with local and international safety standards N (input) and PE shall be bonded. The bonded connection between N (input) and PE must be removed once the AC input is connected. Refer 8.5.4, page 28.
- AC and DC circuits shall be terminated with no voltage / power applied (de-energized).
- The safety standard IEC/EN62040-1-1 requires that, in the event of an output short circuit, the inverter must disconnect in 5 seconds maximum. The parameter can be adjusted on T2S ETH or equivalent device; however, if the parameter is set at a value > 5 seconds, an external protection must be provided so that the short circuit protection operates within 5 seconds. Default setting is 60 seconds.
- The system is designed for installation within an IP20 environment. When installed in a dusty or humid environment, appropriate measures (air filtering ...) must be taken. Installation of filters may result in de-rating of module.
- Environment Conditions:
 - Storage Conditions: -40 to 70°C
 - Relative Humidity: 95%, non-condensing
 - Altitude above sea without de-rating: Less than 1500 m
Greater than 1500 m – de-rating at 0.8% per 100 m

3.3.1 Handling

- The cabinet shall not be lifted using lifting eyes.
- Remove weight from the cabinet by removing the inverter modules. Mark inverter modules clearly with shelf and position for correct rebuild. This is especially important in dual or three phase configurations.
- Empty module positions must not be left open. Replace with blank module or cover.
- This equipment is shipped with a SHOCKWATCH monitor. SHOCKWATCH monitor should be inspected upon receipt of shipment. If the SHOCKWATCH shows that the equipment was exposed to excessive force the warranty will be void.

3.3.2 Surge and Transients Protection

The mains (AC) supply of the modular inverter system shall be equipped with Lightning surge suppression and Transient voltage surge suppression suitable for the application. Follow manufacturer's recommendation for installation. Selecting a device with an alarm relay for function failure is advised.

All sites are considered to have a working lightning surge suppression device in service and installed close enough to ensure effective protection in accordance with best industry practice.

- Indoor sites Min Class II.
- Outdoor sites Min Class I + Class II or combined Class I+II. The modular inverter system/rack can reach hazardous leakage currents. Grounding must be carried out prior to energizing the system. Grounding shall be made according to local regulations.

3.3.3 Other

- Insulation test (Hi-Pot) must not be performed without instructions from the manufacturer. Irreparable damage may occur.

3.4 Maintenance

- The modular inverter system/rack can reach hazardous leakage currents. Grounding must be carried out prior to energizing the system. Grounding shall be made according to local regulations.
- Prior to any work conducted on a system/unit make sure that AC input voltage and DC input voltage are disconnected.
- Inverter modules and shelves contain capacitors for filtering and energy storage. Prior to accessing the system/modules after power down, wait at least 5 minutes to allow capacitors to discharge.
- Some components and terminals carry high voltage during operation. Contact may result in fatal injury.


3.5 Replacement and Dismantling

- ESD Strap must be worn when handling PCB's and open units.
- CE+T cannot be held responsible for disposal of the Inverter system and therefore the customer must segregate and dispose of the materials which are potentially harmful to the environment, in accordance with the local regulations in force in the country of installation.
- If the equipment is dismantled, to dispose of its component products, you must comply with the local regulations in force in the country of destination and in any case avoid causing any kind of pollution.

4. TSI Technology¹

Inverter modules carrying the TSI logo and the EPC mark are triple port converters (AC in, DC in, AC out). Sinusoidal AC output is converted from the AC main source and/or the DC source.

The block diagram below gives an explicit description of the topology and operation.



The module is built around the following sub-converters

- AC to DC at input
- DC to DC at input
- DC to AC at output

The energy can flow either from the AC source or the DC source under the control of the local DSP controller. The output sine wave is constant and disturbance free regardless of the active source due to internal energy buffering,

The function of the BOOST is for circuit protection in the event of a circuit fault condition on the output of the system. When a circuit fault is detected, the system will multiply the output current by approximately 10x to activate the load circuit protection device (breaker/fuse). The duration of the boost is limited to 20 ms. The power for the boost function comes primarily from the AC input through a diode bridge. This has been designed in such a way so that it will not trip the input AC/DC protection devices. This functionality is intended for circuit and equipment protection only. It is not for personnel safety.

The TSI works according to True Redundant Structure (TRS) that features decentralized and independent logic, redundant communication bus and three internal levels of disconnection to isolate a module after internal failure.

The TRS functionality is included in every inverter module. Running them in parallel provides a modular system with no single point of failure, 100% pure sinusoidal output, high system efficiency, and 0 ms source transfer time.

REG modules: Inverter modules carrying the TSI logo together with REG mark are modules working only with DC input. Sinusoidal output is converted from DC and the module operates as a traditional inverter. EPC Mode and the boost are not available with REG modules.

¹ Information and data given in this chapter intend to for an overview on the technology. Detailed features and parameters for each individual module type of the range may differ and should be referred in the dedicated data sheet.

4.1 EPC Mode

- In EPC Mode, the AC Main source is the primary source while the DC source is secondary.
- The TSI is designed to operate on the AC main source on a permanent basis and to deliver output AC voltage with low THD.
- There is no physical difference on the output sine wave whether the source is AC (or) DC. If the AC main source is out of tolerance or drops below acceptable level, the converter seamlessly switches to DC and the converter operates in “Back-up Mode” (Transfer time is 0 ms).
- As soon as the AC main source returns to its normal operating range, the EPC Mode is automatically resumed.
- The EPC Mode offers higher efficiency (up to 96% depending on the model) without compromising the purity of the sine wave output.
- To set EPC Mode in T2S ETH, go to Parameters > Power > General > Source power ratio DC vs AC (%) and enter the value “0”.

4.2 On-line Mode (REG Mode)

- In On-line Mode, the DC source is the primary source of supply while the AC main source works as the secondary source of supply. Switching time between DC input and AC input is 0ms (source transfer).
- The power delivered by the DC source (usually a battery but it could be any other type of DC generator) is converted to provide regulated and transient free AC power to the load.
- In case of short circuit at the load side, the boost is automatically energized for a specific duration to trip downstream protective devices.
- To set On-line Mode in T2S ETH, go to Parameters > Power > General > Source power ratio DC vs AC (%) and enter the value “100”.

4.3 Safe Mode

- Safe Mode uses the DC source as primary source of supply while the AC main source is in secondary standby.
- The AC main source is normally disconnected through an internal relay and is only connected when downstream fault clearance is required (boost) or if the DC source is unavailable.
- The transfer time between DC and AC results in a typical transfer time of 10 ms.
- Safe Mode is used in extremely harsh environments such as railways. Under harsh conditions it provides extra isolation against disturbances carried by the AC main source.
- To set Safe Mode in T2S ETH, go to Parameters > Power > AC In > Mode On Line (Safe) and select “Enable” from drop down list.

4.4 Mix Mode & Walk-in Mode

- Walk-in Mode allows the inverter to come back progressively on the AC priority source after an outage. This is to avoid block loading a generator.
 - To set Walk-in Mode in T2S ETH, go to Parameters > Power > Other > Walk In Mode Time (x10 s) and select “Enable” from drop down list.
- In Mix Mode, the total output load of the module will be shared by both DC and AC input sources.
 - To set Mix Mode in T2S ETH, go to Parameters > Power > General > Source power ratio DC vs AC (%) and enter the value between “0-100”. (0 - only AC, 100 - only DC)

5. Inverter Components

5.1 Inverter module

BRAVO: -48 VDC / 120 VAC, 60 Hz (50 Hz)

- The TSI Bravo is a 2500 VA / 2000 W converter based on the TSI technology (see section 4, page 11).
- The TSI inverter modules are hot swappable and hot pluggable. They are featured with self setting capabilities for easy plug-and-play operation.
- LED's on module front plate display the status of converter and output power.
- Inverter modules can be combined to build any single or multi-phase structures.
- The inverter modules are equipped with soft start.
- The fan is equipped with alarm and run time meter. It is field replaceable.
- 17.13" (D) x 4.02" (W) x 3.46" (H). [435 mm (D) x 102 mm (W) x 88 mm (H)].
- 11 Lbs [5 kg].



Figure 1. TSI Bravo Module

5.2 Sub-rack (Shelf)

- The cabinetized enclosure is built from supporting shelves (sub-rack) designed according to 19inch standard.
- The BRAVO shelf houses max four (4) inverter modules and one (1) T2S interface. Max 10 kVA per shelf.
- Additional shelves can be stacked and interconnected to build more powerful structures.
- The BRAVO shelf is designed with individual DC input, common AC input and common AC output.
- Each bravo shelf is designed for single phase input and output.
- Optional rear cover can be provided for enhanced safety in cabinet.
- 18.9" (D) x 19" (W) x 2U (H). [480mm (D) x 19" (W) x 2U (H)].
- 13 Lbs [6 Kg] empty.



Figure 2. Bravo shelf with modules

6. Accessories

6.1 Monitoring - T2S-ETH

The T2S-ETH is an interface giving access to the TSI modules that are connected together in any TSI systems.

The T2S-ETH doesn't perform any control or management of the TSI system. It can be removed, replaced or moved to another live system without affecting the original TSI system operation nor the target system.

6.1.1 Parameters setting

The T2S-ETH supports IPv4 network and featured with an ETH port at the front. Connected to a laptop, it enables TSI system settings, modules and phase assignments, and other various adjustments to allow TSI best fit with actual site conditions.

6.1.2 System diagnostic and troubleshooting

The T2S-ETH is featured with a built-in user interface to allow on-line diagnostic through the laptop.

Installers and maintenance technicians should always carry a proper laptop to access/reconfigure the system on-site.

6.1.3 Section Monitoring

The T2S-ETH monitors max of 32 system modules.

The T2S-ETH is featured with:

- 3 digital output alarm contacts
- 2 digital input contacts
- MODBUS
- Alarm monitoring
- Log file of the latest 2000 events as FIFO
- SNMP v1 through T2S-ETH
- SNMP v2c and v3 through Inview X (If T2S-ETH is connected to Inview X)
- Power: 2 W



Figure 3. Monitoring - T2S-ETH

Note:

Operation of T2S-ETH is described in a separate manual available upon request.

Some systems may be ordered with a T2S-USB. Manual available upon request.

6.2 Monitoring - Inview X

Inview X is an advanced monitoring and controller unit for power systems. It allows the user to easily view, access, configure the system information through LCD screen graphic display and web interface.

The Ethernet ports in Inview X allow multiple communication points for remote communication, Web interface, and connecting the accessories such as Measure Box Battery, Measure Box DC load, and Measure Box AC.

Inview X interface provides the user access to the configuration and setup files of the modules that are connected in the system. It is also a controller for DC regulation.



Figure 4. Monitoring - Inview X

Inview X is featured with the following:

- Monitor up to 32 converters, and with Power Extension Kits, it can monitor up to 270.
- 7" LCD touch screen display with LED strip around the screen to indicate Major alarm, minor alarm and system status.
- Two Digital Inputs and two Output Relay contacts.
- Higher Temperature Resistance
- Records 5000 events as FIFO

6.2.1 Inview X - Connections


Inview X has multiple network ports and inbuilt free potential contacts.



- **ETH** ports are used for network connectivity, and user can access the system information through the web interface.
 - **ETH Front:** DHCP server, providing access to the configuration at URL <https://inview.local> or <https://10.250.252.1>
 - Intended for direct connection of a laptop computer.
 - Warning:** Do not connect this port to the network, as it might interfere with other DHCP servers.
 - **ETH1:** Main network interface
 - Default static IP address: 10.250.250.1/24
 - It can be configured to other static addresses or as a DHCP client in a web-based configuration interface

- **ETH2: Secondary network interface**
 - Static IP address: 192.168.0.3/24
 - It is dedicated to T2S-ETH and does not connect to the network
- **CAN MB port** is used to share the system information to the Measure Box Battery. It also provides the +12 Vdc power to three accessories which are connected in series.
- **Power:** The unregulated separate +48 V power supply is required for powering Inview X and this power should not be shared with other devices.

6.2.2 Inview X and T2S-ETH Connection



6.3 Manual Bypass

The Manual Bypass operates via manually operated switches to create a connection from the AC main input directly to the output AC distribution. Standard Manual Bypass are “Make before Break”. When engaged or disengaged, no disturbance is transmitted to the load.

When MBP is engaged, inverter modules are switched off and can be removed without impacting the load. The DC source is not physically disconnected. After disconnecting the DC source (By opening the DC Breakers), the shelf section is safe for maintenance.

When in **NORMAL mode**, power is supplied to the TSI Inverter modules’ AC input. Clean, stable AC out is supplied to the critical load.

When in **BYPASS mode**, the Mains AC input is passed directly to the critical load. The critical load is subject to any AC mains disturbances. Prior to engaging BYPASS mode, appropriate precautions should be taken to ensure continuity of power to the critical load.

The INTERIM position is to allow the modules to restart when returning from BYPASS. When transferring the load to BYPASS, the operator does not need to stop in the INTERIM position. When returning from BYPASS, the switch shall be left in the INTERIM position until the top-left LED on each module has turned green.

See section “11. Manual Bypass Operation”, page 54 for more information.

NOTE:

When the system is in Bypass the load is subjected to AC main disturbances.

An internal MBP must be present if connection is made via a non-CE+T external MBP.



Figure 5. MBP Switch

6.3.1 EMBS

“See EMBS User Manual” for more information.

6.4 Surge Arresters

The mains (AC) supply of the modular inverter system shall be fitted with suitable Lightning surge suppression and Transient voltage surge suppression. Manufacturers installation guidelines shall be followed. It is advised to select a device with an alarm relay contact for notification.

All sites are considered to have a working lightning surge suppression device in service.

- Indoor sites Min Class II.
- Outdoor sites Min Class I + Class II or combined Class I+II.

Surges from induced lightning and power switching operations are smaller but are more numerous and can result in equipment misoperation, lockup or damage.


Inverter damage caused by improper surge protection are not covered by CE+T product warranty.

7. MIPS Design and Description

7.1 System Design

MIPS is a cabinetized modular inverter specifically designed for clean and temperature controlled environments.

- Telecom grade design.
- Based on TSI BRAVO – 120 VAC Inverter Module.
- Fully modular.
- Supports redundant configurations.
- Supports EPC mode.
- Cabinet NEMA 1 (IP 20)
- The cabinet requires air flow out the rear of the modules and is not designed to be installed back against a wall. Maintain 36" space of air flow and maintenance access per NEC.



Picture is given for illustration only.
Some accessories shown may be optional.

Figure 6. MIPS 75 KVA Inverter System

7.2 System Description

MIPS comes fully equipped with

- Individual DC protection for modules.
- MBP included by default (can be removed on request).
- EMBS available upon request.
- Inview X or CANDIS shelf and display (one display per phase configured).
- TCP-IP interface (included by default).
- T2S interface.
- AC input breaker (bulk)-supplementary type (can be removed on request).
- AC output breaker (bulk)-branch circuit protection (can be removed or replaced by supplementary type on request).




Figure 7. MIPS 75 kVA System - General Arrangement

Options

- Surge Arrestors (Installed by default)
- Door
- DC Disconnect
- External Manual Bypass Switch (EMBS)

7.3 MIPS Single phase Configuration - 120 VAC

A single phase system is 120 VAC from L to N. Input and output are the same, consisting of 2 wires + (PE) Ground.

System Designation	Max Power (kVA)	Max power (KW)	Number of Shelves	Max number of Modules
MIPS-1-20-xx-08	20	16	2	8
MIPS-1-25-xx-10	25*	20*	3	10 (12**)

* : This configuration doesn't use all available slots.

** : Up to 2 modules can be allocated to redundancy.

System Designation	Bulk DC*** input			2 DC*** input		
	Fuse or Breaker	Cable Min	Cable Max	Fuse or Breaker	Cable Min (per feed)	Cable Max (per feed)
MIPS-1-20-xx-08 48 Vdc	500 A	2 x 300 MCM or 3 x 3/0 AWG	9 x 500 MCM	2 x 250 A	1x 300 MCM or 2 x 1/0 AWG	3 x 500 MCM
MIPS-1-25-xx-10 48 Vdc	600 A	2 x 500 MCM or 3 x 4/0 AWG	9 x 500 MCM	2 x 300 A	1 x 500 MCM or 2 x 2/0 AWG	3 x 500 MCM

† Use double-pole breakers for both positive (+) and negative (-) when DC voltage is greater than 75 Vdc.

*** : Refer Section 8.5.5, page 29.

System Designation	AC input & AC output				
	Branch Protection		Supplementary Protection		Cable Max Based on Terminal Size
	Breaker	Cable Min	Breaker	Cable Min	
MIPS-1-20-xx-08	225 A	250 kcmil	200 A	4/0 AWG	300 kcmil
MIPS-1-25-xx-10	250 A	300 kcmil	225 A	250 kcmil	300 kcmil

Note:

By default input and output breakers are installed in the cabinet with above mentioned rating.

Input breaker is "Supplementary", an additional branch protection, supplied by customer, should be installed in main switch gear. Output breaker is "Branch" and can be directly connected to downstream distribution panel.

7.4 MIPS Single Phase Configuration - 240 VAC

A split phase system is 120 VAC from L to N and 240 VAC from L1 to L2 and L1 and L2 are phase shifted by 180 degrees. (For 208 VAC systems, the phase shift can be set to 120 degrees). Input and output are made upon 3 wires + Ground, cabling and phase shift must match.

System Designation	Max Power (kVA)	Max power (KW)	Number of Shelves	Max number of Modules
MIPS-2-20-xx-08	20	16	2	8**
MIPS-2-40-xx-16	40	32	4	16**
MIPS-2-50-xx-20	50***	40***	6	20**/*** (24****)

* : Also known as “Single Phase 240VAC” (including UL). Number of wires is always meaningful to distinguish from other single phase.

** : Number of modules must be even, with same number in each phase in order to comply with UL recommendations.

*** : This configuration doesn't have all slots in use.

**** : Up to 2 x 2 modules can be allocated to redundancy.

System Designation	Bulk DC*** input			2 DC*** input		
	Fuse or Breaker	Cable Min	Cable Max	Fuse or Breaker	Cable Min (per feed)	Cable Max (per feed)
MIPS-2-20-xx-08 48 Vdc	500 A	2 x 300 MCM or 3 x 3/0 AWG	9 x 500 MCM	2 x 250 A	1 x 300 MCM or 2 x 1/0 AWG	3 x 500 MCM
MIPS-2-40-xx-16 48 Vdc	1000 A	3 x 500 MCM or 4 x 300 MCM	9 x 500 MCM	2 x 500 A	2 x 300 MCM or 3 x 3/0 AWG	3 x 500 MCM
MIPS-2-50-xx-20 48 Vdc	1200 A	4 x 500 MCM or 6 x 4/0 AWG	9 x 500 MCM	2 x 600 A	2 x 500 MCM or 3 x 4/0 AWG	3 x 500 MCM

† Use double-pole breakers for both positive (+) and negative (-) when DC voltage is greater than 75 Vdc.

***** : Refer Section 8.5.5, page 29

System Designation	AC input & AC output				
	Branch Protection		Supplementary Protection		Cable Max Based on Terminal Size
	Breaker	Cable Min	Breaker	Cable Min	
MIPS-2-20-xx-08	125 A	1 AWG	100 A	2 AWG	1 AWG
MIPS-2-40-xx-16	225 A	250 kcmil	200 A	4/0 AWG	300 kcmil
MIPS-2-50-xx-20	250 A	300 kcmil	225 A	250 kcmil	300 kcmil

Note:

By default input and output breakers are installed in the cabinet with above mentioned rating.

Input breaker is “Supplementary”, an additional branch protection, supplied by customer, should be installed in main switch gear. Output breaker is “Branch” and can be directly connected to downstream distribution panel.

Neutral must be landed on both input and output terminals.

7.5 MIPS Three Phase Configuration - 208 VAC

Three phase systems are 120 VAC L to N and 208 VAC from L1 to L2, L1 to L3, L2 to L3. Input and output are made upon 4 wires + (PE) Ground, “Y” or “Star” connection. All phases are phase shifted by 120 degrees one to the other.

System Designation	Max Power (kVA)	Max power (KW)	Number of Shelves	Max number of Modules
MIPS-3-30-xx-12	30	24	3	12 *
MIPS-3-60-xx-24	60	48	6	24 *
MIPS-3-75-xx-30	75	60	9	30 *

* :Number of modules must be multiple of 3, with same number in each phase in order to comply with UL recommendations.

System Designation	Bulk DC*** input			2 DC*** input		
	Fuse or Breaker	Cable Min	Cable Max	Fuse or Breaker	Cable Min (per feed)	Cable Max (per feed)
MIPS-3-30-xx-12 48 Vdc	700 A	3 x 300 MCM or 4 x 3/0 AWG	9 x 500 MCM	3 x 250 A	1 x 300 MCM or 2 x 1/0 AWG	2 x 500 MCM
MIPS-3-60-xx-24 48 Vdc	1600 A	5 x 500 MCM or 7 x 300 MCM	9 x 500 MCM	3 x 500 A	2 x 250 MCM	2 x 500 MCM
MIPS-3-75-xx-30 48 Vdc	2000 A	6 x 500 MCM or 8 x 300 MCM	9 x 500 MCM	3 x 600 A	2 x 500 MCM	2 x 500 MCM

† Use double-pole breakers for both positive (+) and negative (-) when DC voltage is greater than 75 Vdc.

*** : Refer Section 8.5.5, page 29

System Designation	AC input & AC output				
	Branch Protection		Supplementary Protection		Cable Max Based on Terminal Size
	Breaker	Cable Min	Breaker	Cable Min	
MIPS-3-30-xx-12	125 A	1 AWG	100 A	2 AWG	1 AWG
MIPS-3-60-xx-24	225 A	250kcmil	200 A	4/0 AWG	300kcmil
MIPS-3-75-xx-30	250 A	300kcmil	225 A	250kcmil	300kcmil

Note:

Sometimes three phase systems with 2 legs instead of three can be requested. They can be called split phase or dual phase. Effectively they are based upon same hardware than split phase (see section 7.4, page 21) with 3 wires (L1-L2-N) . Since phases are shifted by 120 degree the L1 - L2 output voltage is 208VAC.

Three phase configuration can be connected to 240VAC L-L(138VAC L-N) sources. Refer to supplier for specific recommendations and approval. By default input and output breakers are installed in the cabinet with above mentioned rating.

Input breaker is “Supplementary”, an additional branch protection, supplied by customer, should be installed in main switch gear. Output breaker is “Branch” and can be directly connected to downstream distribution panel.

Neutral must be landed on both input and output terminals.

7.6 MIPS Module Based Current Ratings

# Modules	Rated AC Input / Output Current per Phase (Amps)	Rated DC (48V) Input Current per Polarity (Amps)
120 Vac – Single Phase – 2 Wires + PE (L-N+G)		
1	20.83	48.00
2	41.66	96.00
3	62.49	144.00
4	83.32	192.00
5	104.15	240.00
6	124.98	288.00
7	145.81	336.00
8	166.64	384.00
9	187.47	432.00
10	208.30	480.00
120/240 Vac – Single Phase – 3 Wires + PE (L-L-N+G)		
2	20.83	96.00
4	41.66	192.00
6	62.49	288.00
8	83.32	384.00
10	104.15	480.00
12	124.98	576.00
14	145.81	672.00
16	166.64	768.00
18	187.47	864.00
20	208.30	960.00
120/208 Vac – Three Phase – 4 Wires + PE (L-L-L-N+G)		
3	20.83	144.00
6	41.66	288.00
9	62.49	432.00
12	83.32	576.00
15	104.15	720.00
18	124.98	864.00
21	145.81	1008.00
24	166.64	1152.00
27	187.47	1296.00
30	208.30	1440.00
Upstream / downstream protections and field wiring should be based on the maximum number of modules for the system.		

8. System Installation

8.1 Site Preparation

- Input and output protection.

When installing MIPS inverter systems, UL489 listed AC upstream (input) and downstream (output) circuit breakers are required. Refer Section 7.3, page 20, 7.4, page 21, and 7.5, page 22 for breaker sizes.

At MIPS Input

Branch circuit protection breaker should be provided in upstream switchgear regardless of any protective device already installed at the input of the MIPS.

At MIPS Output

Whenever the MIPS is supplied with supplementary output breaker or without any protective device at all (see option listed in 7.2, page 19), appropriate protection should be provided on site according to following table:

Output distribution should be structured to guarantee tripping segregation. Contact manufacturer for recommendations and calculation methodology.

- Refer to Section 7, page 18 for sizing over current protection and cables. All cables should be copper wire and must be rated for min 90°C (194°F).
- All cables must be C-UL-US or CSA Listed cables.
- All cables lugs must be C-UL-US or CSA listed. They must be sized according to the rated current of the inverter system and to the customer terminal connection.
- Wire all positions for future expansion.
- All AC input, AC output, DC input, and signal cables shall be kept separated.
- Cable crossings shall be arranged at 90 degree angles.
- Empty inverter positions shall be covered with blank module covers
- System cooling – The System should not be installed with the rear of the unit at, near, or up against a wall
 - **A minimum of 16 inch clearance is required on the rear of the cabinet.**
 - **A minimum of 6 inch clearance is required on top of the cabinet.**
- The System is designed to operate in a temperature controlled (maximum operating ambient 40°C/104°F) and clean environment. The presence of airborne particles such as dust, sand and metallic debris are forbidden. Appropriate filters shall be installed.
- Heat Load Calculation - The system heat loss can be calculated by taking the system size in KW and multiplying by 375.2 BTU/hr.

Warning:

Filters mounted to the air inlets reduce the air pressure and may cause inverters to cut off by thermal runaway. De-ratings should apply. Refer to supplier for specific recommendations and approvals.

Corrosive chemicals and contaminants in the air or in the vicinity of the system are forbidden. Refer to supplier for specific treatments in industrial and maritime areas.

8.1.1 Transformer and Generator Sizing

The inverter is capable of operating at 150% of rated capacity for 15 seconds. The boost function allows up to 10 times the rated inverter capacity for 20 ms to clear downstream faults.

- Transformers supplying AC to the inverter should be sized at a minimum of 1.5 times the kVA rating of the inverter to meet this requirement.
- Generators supplying emergency AC to the building and to the inverter should be sized at a minimum of 2 times the kVA rating of the inverter.
- If the transformer/generator's voltage output waveform can be guaranteed without oscillation even when the TSI system operates under overload conditions of 150% for 15 seconds, then the transformer/generator's sizing could be 1:1 rating of the TSI system.

8.2 Packaging Information

CE+T cabinets are always fixed on a pallet, and then packed in a wooden crate. These crates are usually delivered laying flat, horizontally.

To unpack your cabinet, we recommend the following method:

- Make sure that the crate is laying flat, with the correct side up. This side is identified by a double red arrow.
- Remove the top cover in order to be able to identify the top and bottom sides of the cabinet.
- Raise the crate vertically with the top side of the cabinet up. Make sure that the cabinet does not fall forward out of the crate while you do so.
- Remove the cabinet and its attached pallet from the crate.

If you prefer to take the wooden crate apart before raising the cabinet, make sure you do not damage or dent the cabinet while doing so.

Warning: The top cover fixing bolts may NEVER be replaced with lifting eye bolts.




Figure 8. Cabinet Lifting

8.3 Module packing

Modules ordered with system are packed separately in a carton or a pallet. They come labelled. Please insert modules in the preassigned slots.

If the modules have been ordered separately they are packed in carton on pallet. Refer to installation procedure to address modules.

Module packing material shall be taken apart and stored in case of return under warranty. Improper packing of a returned module may void the warranty.




Figure 9. Module Description

8.4 Anchoring the cabinet to the floor

The cabinet is anchored through the base of the cabinet.

Remove lowest front cover to get access to the anchoring locations.

Max screw diameter is 0.8" (22 mm). See Hole pattern, foot print. For foot print measurements.




Figure 10. Anchor hole locations

8.5 Cabling

Check section 7, page 18 to identify system configuration and refer to section 7.3, page 20, 7.4, page 21 and 7.5, page 22 for cable sizes. Refer also to 8.1, page 24 for important safety notices.

8.5.1 Tightening Torque

Torque recommendation for cable termination are:

8.5.1.1 AC Connections (per Mfg)

Terminal Block	Tightening Torque Nm
MIPS (Small TB*)	10
MIPS (Large TB**)	20

Figure 11. Torque Table - AC Connections

* For MIPS, small terminal block is for MIPS-1-10, MIPS-1-20, MIPS-2-20, MIPS-3-30

** For MIPS, large terminal block is for MIPS-1-25, MIPS-2-40, MIPS-2-50, MIPS-3-60, MIPS-3-75

8.5.1.2 DC Connections (per NEC)

Size of wire [AWG/kcmil]	Tightening Torque Nm
2 - 1	16.9
1/0 - 2/0	20.3
3/0 - 4/0	28.2
250 - 350	36.7
500	42.4
600	
750	

8.5.2 Cable Inlets

Use appropriate conduit fitting to attach the conduits to the top of the cabinet. Use existing knock outs and do not block the airflow through the top of the cabinet. The top panel can be removed to facilitate wiring.




Figure 12. Cable Inlet - Positions

8.5.3 Grounding

Main protective conductor(PE) connection is made to the X2(AC IN) terminal block marked with symbol for identification.

PE must be terminated even if commercial Mains is not available and shall be connected to building or main panel ground.



Recommended Cable cross section is the size equal (min) to Neutral cable cross section. Adhere to local regulations.
(See section 8.5.4, page 28)

Ground has to be connected in accordance with local code.

Note: Connection in yellow-green are factory wired and shall not be removed. (In the below image the connection is shown in green color).




Figure 13. Earthing connections

8.5.4 AC Input and Output

The pictorial representation of terminal blocks arrangement is as follows.

Warning: If AC IN is connected, remove the Neutral bonding jumper cable between X2 (AC IN) and frame ground.





Figure 14. Neutral bonding jumper

AC input and AC output shall be wired to connecting terminal blocks as per following indications:



When connecting AC input and output cables, you must remove the washer from the terminal block prior to landing the cable lug.

Reinstall the washer between the cable lug and the nut.

8.5.5 DC Input

8.5.5.1 Single feed DC Input

- One (1) common DC connection.
- Two holes of $\frac{3}{8}$ " threaded hole with 1" (25.4 mm) between center.
- Internal DC distribution with circuit breakers (Q01-Q30) to each inverter module.
- Max 9 x 500 kcmil (240 mm²) cables.
- Can be single or double lug (refer to site requirement).




Figure 15. Single Feed DC - Bus Bar

Note: Screws, nuts and cable shoes are not included in the delivery.




Figure 16. Single Feed DC - Negative bar hole details

8.5.5.2 Dual DC Feed Input

- 2 x DC input connection per system.
- Two holes of $\frac{3}{8}$ " threaded hole with 1" (25.4 mm) between center.
- Internal DC distribution with circuit breakers (Q01-Q30) to each inverter module.
- Max 3 x 500 kcmil (240 mm²) per pole (group).
- Can be single or double lug (refer to site requirement).

Note: Screws, nuts and cable shoes are not included in the delivery.




Figure 17. Dual DC Feed - Bus Bar






Figure 18. Dual DC Feed - Negative bar hole details

8.5.5.3 Dual DC Feed - Internal Wiring Pattern

Single Phase System



Split Phase System



8.5.5.4 Triple DC Feed Input

- 3 x DC input connection per system.
- Two holes of $\frac{3}{8}$ " threaded hole with 1" (25.4 mm) between center.
- Internal DC distribution with circuit breakers (Q01-Q32) to each inverter module.
- Max 2 x 500 kcmil (240 mm²) per pole(group).
- Can be single or double lug (refer to site requirement).

Note: Screws, nuts and cable shoes are not included in the delivery.




Figure 19. Triple DC Feed - Bus bar positions





Figure 20. Triple DC Feed - Negative bar hole details

8.5.5.5 Triple DC Feed Input - Internal Wiring Pattern

Three Phase System


 **DC IN 1**
 **DC IN 2**
 **DC IN 3**

3 x 10 kVA
3 P




 **DC IN 1**
 **DC IN 2**
 **DC IN 3**

3 x 20 kVA
3 P



 **DC IN 1**
 **DC IN 2**
 **DC IN 3**

3 x 25 kVA
3 P



8.5.6 Signaling

All relays are shown in non energized state.





Figure 21. Alarm dry contacts



Note:

Output relays are time delayed factory default set to 30 seconds, User settable from 2 to 30 seconds.

To connect "Inverter in Bypass" status signal from inverter to External Manual Bypass (MBP) Switch, connect external MBP to X3 terminals 7 and 9.

8.5.6.1 Alarm (X3)

- Relay characteristics X3 (Major (UA), Minor(NUA), Prog)
 - Switching power 60 W
 - Rating 2 A at 30 VDC / 1A at 60 VDC
 - Max wire size 17 AWG (1 mm²)

Relays are energized when idle and contacts are released when event occurs.

8.5.6.2 Digital In (X5)


- Input characteristics X5 (Digital In 1, Digital In 2)
 - Signal voltage +5 VDC (galvanically isolated)
 - Max wire size 17 AWG (1 mm²)

Note: Not available if internal MBP is installed.

8.5.6.3 Remote ON/OFF (X6)

Note: The system is by default equipped with a connection between pin 3 and 2. If remote ON/OFF is not used the strap shall remain. Should the remote ON/OFF be used the strap must be replaced with a changeover contact or emergency button.

- The remote ON/OFF turns the AC output OFF.
- Input AC and input DC is not affected by the remote ON/OFF.
- The remote ON/OFF requires changeover contacts, one input opens as the other closes. If both transitions are not picked up the status is not changed.
- Digital input characteristics (Remote ON/OFF)
 - Signal voltage +5 VDC (galvanically insulated)
 - Max wire size 17 AWG (1mm²)



Functional table for remote ON/OFF function

#	Pin 1-3	Pin 2-3	Status	Indication
1	Open	Open	Normal operation	All (Green)
2	Closed	Open	OFF	AC output (OFF) AC Input (Green) DC Input (Green)
3	Open	Closed	Normal operation	All (Green)
4	Closed	Closed	Normal operation	All (Green)

Warning: If remote ON/OFF not used, pin 2 and 3 MUST be bridged together!

8.6 Switching OFF MIPS System

Perform the following steps to Switch OFF the MIPS System.

Caution: While switching OFF the System, the power to load will be disconnected.


1. Switch OFF AC Output Breakers.
2. Switch OFF AC Input Breakers.
3. Switch OFF DC Input Breakers.
4. Switch OFF the Upstream and Downstream and Bypass Breakers. (As applicable)

CAUTION - Risk of electric shock. Capacitors store hazardous energy. Do not remove any modules from the cabinet for at least 5 minutes after disconnecting all sources of AC or DC supply.

Caution - Risk of electric shock. This inverter receives power from more than one source. Disconnection of AC source and DC source is required to de-energize this unit before servicing.

9. Human-Machine Interface

9.1 Inverter module



Inverter Status LED	Description	Remedial action
OFF	No input power or forced stop	Check environment
Permanent green	Operation	
Blinking green	Converter OK but working conditions are not fulfilled to operate properly	
Blinking green/orange alternatively	Recovery mode after boost (10 In short circuit condition)	
Permanent orange	Starting mode	
Blinking orange	Modules cannot start	Check T2S
Blinking red	Recoverable fault	
Permanent red	Non recoverable fault	Send module back for repair

Table 1. Module Inverter LED's - Indications

Output Power (redundancy not counted)						Output Power (redundancy not counted)
<5%	5% to 40%	40 to 70%	80 to 95%	100%	100% = overload	Status output power LED
×	×	×	≡	≡	≡	
×	×	≡	≡	≡	≡	
—	—	—	×	—	—	Behaviour (B - Blinking : P - Permanent)
1B	1P	2P	2P	3P	3B	

Table 2. Module Power LED's - Indications

9.2 T2S-ETH

- Alarm indication on Inview X (Urgent / Non Urgent / Configurable)
 - Green: No alarm
 - Red: Alarm
 - Flashing Exchanging information with inverters (only Configurable alarm)
- Outgoing alarm relay delay time
 - Major and Minor Adjustable from 2 to 60 seconds
- Parameter setting via Laptop.
- Factory default according to list of set values.

Note: To know more details, refer to T2S-ETH user manual.




Figure 22. T2S-ETH Front details

9.3 Graphical User Interface - Inview X

The user interface is the same if accessed with a laptop connected on front ETH connection, remotely on a network, or through Inview X if one is present.

The interface has a “top-down” philosophy: the first screen gives a general overview, then one can go deeper and get more information on a specific area by clicking the “magnifier icon.”

9.3.1 Inview X - LCD Interface

Inview X LCD interface is a 7-inch touch screen. Through the LCD interface, the user can view and access the system details. Once the system is powered upon, the Inview X is up and ready for operation.

Note: Interface graphics and layout may change based on the system configuration.





Figure 23. Inview X - LCD Interface

- **[1] Header:** Displays the Site name, Date and Time.
 - **Events:** Tapping on  goes to Alarms and Events screen.
 - **Administration:** Tapping on  provide access to different action screens.
- **[2] Interface Area:** Tapping on the widget provides the corresponding parameter information.
 - Provides information about the corresponding screen. In some screens, left and right navigation buttons appear, indicating more screens are present.
- **Navigation arrows** for the next and previous pages. Up and down arrows appear on some screens, indicating more information is present.

9.3.2 Inview X - LCD Menu Structure

The below tree provides an overview of the menu structure in the Inview X LCD interface.



9.3.3 Inview X - LED Indications

Three LED's are present behind the front white plastic of the controller to indicate major alarm, minor alarm, and system status. These LED's are not visible until they illuminate during the corresponding action occurs.

Light Blue: Normal Operation

Orange: Minor Alarm

Red: Major Alarm




9.3.4 Inview X - Web UI

Open the web browser and type the default IP address **10.250.250.1/ site**, in the address field and press enter.

Inview X has three login – Basic, Expert and Admin. All three logins are password protected.

The default password for all three logins is “1234”. It can be modified, refer to Inview user manual for more details.

NOTE: The user is not allowed to modify any converter system parameter inside the Inview X Web UI.



The screenshot shows the login interface of the Inview X Web UI. It includes a "User name" field with "Admin" entered, a "Password" field with four dots and a toggle icon, a "Password lost?" link, a red "LOGIN" button, and a language selection option "English (EN)".

9.3.5 Software Overview


The software embedded in Inview X allows complete system supervision through web browser, and provides functionalities such as:

- System status and information display.
- System alarms and events log file.

In addition to these, there is minimal information available via “touch screen display”.


9.4 Inview X Software Verification and Configuration

1. Click on **Administration**  **button on the Inview Display > System Information** to verify the Inview software 6.1.0+2467 or higher.



2. Open the Network and Internet settings on the laptop, click on 'Change adapter' option, right click on 'Ethernet', click on 'Properties', choose 'Internet Protocol Version 4 (TCP/IP)' and set the values as shown below::
 - Set IP address: 10.250.250.4
 - Subnet: 255.255.255.0
 - Gateway: 10.250.250.254
3. Enter the web browser IP address: **10.250.250.1/dashboard** to open the user interface of Inview X.
 - Username: **Admin** (Case Sensitive)
 - Password: **1234**
4. If necessary, update the Inview X software to 6.1.0+2467.

Click on **Administration**  **button > Software Update > Choose file > Upload**, save configuration and reboot.



5. Upload the file 'Configuration.xml'.
Click on **Administration > Configuration > Chose file > Upload** and apply parameters.


Multiple parameter modification from file

- ➔ 1º/ The parameter modifications listed in the configuration file will be applied to the running site.
- ➔ 2º/ Please Save Configuration to persist changes or reboot without saving to reset to the previous configuration.

No file chosen


Please select a 'configuration*.xml' file

- Click on *Admin* --> *Save Configuration*, and then click on 'Save and reboot the controller'.




9.5 Inview X - Inverter Connection


- In the Inview X web UI, select "Advance View"
- Click on *Site > Configuration > CF220*, change the Extension Configuration to T2S-ETH (192.168.0.2,es1_invs1) and click on "Apply and Save" as shown below.




Note: After selecting "Apply and Save", Inverter System will be listed on the left side menu.



- Click on *Energy System > Description > Connected Assets*, change the value of DE500 to 3, DE510 to Grid, DE511 to Grid, DE520 to DC Source, DE521 to DC Source, DE530 to AC Load and DE531 to AC Load as shown in picture below. Remember to save the changes.




- Click on to *Inverter System > Description > Asset Connection > DE501* (change the value to AC Load), DE502 (change the value to Grid), DE503 (change the value to DC source). Remember to save the changes.



ID	NAME	VALUE
DE100	Declared Type	T2SETH
DE101	IP Address	192.168.0.2
DE102	System Name	CE+T
DE103	System Description	T2S-ETH supervisor for TSI SNMP V1.0
DE104	System Location	USA

ID	NAME	VALUE
DE501	AC Outputs	AC Load
DE502	AC Inputs	Grid
DE503	DC	DC Source


- Click *Admin > Save configuration* as shown in picture below.



Quick Links

- Save Configuration
- Save Inventory
- Reboot Controller
- Save Configuration and Reboot Controller


- Click on the INVIEW logo located on the top left corner of the GUI and click on 'Dashboard' tab. The dashboard screen will appear as shown below.



Description	
Description - Address - City	undefined
Controller - Software - Running	Inview Compas
Compas Informational Version	6.1.0-3+1638
Controller - Software - Running	6.1.0.3
Compas Version	
Controller - Hardware - Platform	Inview X

Data	
Network - IPv4 Address	10.250.250.1
Time - Local Date And Time	10-26-2023 09:52:29 am


7. Click the drop-down arrow of the Inverter System to verify the amount of the installed inverter modules. Click on Data tab to see the Global AC output details.



The screenshot shows the INVIEW web interface. On the left, the 'INVERTER SYSTEM' dropdown menu is expanded, showing a list of inverters: INVERTER #1 (3285), INVERTER #2 (3301), INVERTER #3 (3154), INVERTER #4 (3288), INVERTER #5 (3023), and INVERTER #6 (3298). The 'Data' tab is selected in the top navigation bar. The main content area displays 'AC Outputs' with a table of data points.

ID	NAME	VALUE
Global		
DA103	Active Power	0 W
DA104	Apparent Power	118 VA
DA105	Frequency	50 Hz
DA106	Status	OK
DA111	Installed Active Power	14400 W
Phase 1		
DA121	Voltage	238.00 V
DA122	Current	0.26 A

8. Click on Administration  button, scroll the left side menu and select the IP address of the T2S-ETH (192-168-0-2).



The screenshot shows the INVIEW web interface in the Administration section. The left sidebar menu is expanded, and the '192-168-0-2' option is selected. The main content area displays a dashboard with various management options: Users, Software Update, Configuration, Inventory, and Languages.


9. Click the “Open in new tab” button.



The screenshot shows the INVIEW web interface with the 'Web Server > 192-168-0-2' page. The 'Open in new tab' button is highlighted in the bottom right corner.

10. Now, a traditional T2S-ETH GUI will open in a new tab as shown below.

Note: If the page does not load, refresh the browser (F5).




Note: End users or Technicians can use this traditional GUI to configure the Inverter.


- Username: **Expert** (case sensitive)
- Password: **pass456**

11. Instruction to change the inverter system's default IP address:

- Connect your computer to the inverter system's Customer connection (RJ45) port with an ETH cable
- Set the computer TCP/IPv4 as below:
 - IP address: 10.250.250.4
 - Subnet mask: 255.255.255.0
 - Default gateway: 10.250.250.1
- Enter 10.250.250.1/site in a web browser address bar and Log in with the username: Admin (Case Sensitive) and password: 1234
- Click on Site->Configuration
- Click on the Pen (Edit) on the right panel to change the IP address (CF2) and Subnet mask (CF3).



- f) Click on Apply-> Apply and Save->User Context (upper right corner) ->Save configuration and reboot the controller.
 - g) The new IP address will be affected after the InviewX display finishes the rebooting (about 10 minutes).
12. Make sure that the AC input, DC, and AC output LEDs of all the modules are illuminated in solid green.
 13. On the Inview X display, touch the AC input, AC output and DC Source widgets to verify the data.




Grid				AC Load			DC Source	
	L1	L2	L3		L1	L2	L3	
State	-	-	-	State	OK	OK	OK	DC1
Voltage	122 V	123 V	121 V	Voltage	123 V	123 V	123 V	State
Current	500 mA	1.10 A	1.60 A	Current	940 mA	1.79 A	830 mA	Voltage
Frequency	60.0 Hz	60.0 Hz	60.0 Hz	Frequency	60.0 Hz	60.0 Hz	60.0 Hz	Current
Active Power	0.00 W	0.00 W	0.00 W	Active Power	38.0 W	44.0 W	38.0 W	Power
				Apparent Power	115 VA	220 VA	102 VA	

9.6 Accessing the T2S-ETH GUI via Inview X (software version 6.2.0 and above)

The T2S-ETH Graphical User Interface can be accessed via Inview X if the software version is 6.2.0 or above.

Note: Radius protocol is not applicable if the T2S-ETH graphic user interface is used on the Inview X display

1. In the Inview X web UI, select 'Advance View'
2. Click on Site --> Configuration --> CF220, change the Extension Configuration to CATENA(192.168.0.2,s) and click on 'Apply and Save' as shown below



3. The T2S-ETH UI can now be seen on the Inview X display.



9.7 T2S - Web UI

NOTE: The controller will perform a short self-test as it boots up. Alarm alerts are normal.

- Initiate the start-up of the display Inview/Catena by closing the protection breakers)
- Connect a computer to the customer connection port (RJ45) on the Inverter system via an ETH cable

The T2S-ETH web UI can be accessed through <http://10.250.250.1>


There are two access levels:

- **Basic login** can only browse the pages and download the files.
- **Expert login** can access and also modify the system parameter values. The default password is **pass456** but it's strongly advised to users to change that password.

NOTE: System modification and setting may result in alarm event. Be careful while applying modification.


An auto-logout feature is available to avoid a user being connected all the time, blocking the system.

No password is required for Basic, but Expert mode is protected with a default password “**pass456**” and it can be modified.




9.8 Interface Areas

- 1 → Banner
- 2 → Main Area
- 3 → Tool bar



9.8.1 Banner



1 → T2S Mode

T2S-ETH can be used redundant (2 in the same system), one being master, the second is a slave. When used alone, T2S-ETH automatically becomes master.

2 → Site name

It's a customizable field from the configuration menu. Users can set any string as required.


3 → Access level

Display the level in use to browse the interface. It can be either Expert or Basic.

4 → Date and time

This is the device time and date which can be adjusted in configuration menu.

9.8.2 Main Area



The above screen is a "Classic" home page, and the moving white ball appears, while the load consumes power from the module. While in the "Alternate" home page, displays brief information of the system.

1 → AC IN

Clicking the magnifier  will bring the user to all measurements regarding the AC input. The LEDs show the status of the input: if the source is absent, this LED's becomes red. Flowing (moving white ball) from this item to the system means power is taken from the source. The power displayed is the total power consumed, regardless of the system is 1P or 3P.

2 → DC input

Clicking the magnifier  will bring the user to all measurements regarding DC input. Given the system can be configured with up to 2 DC groups, power is the total power consumption. Flowing (moving white ball) from this item to the system means power is taken from the DC source.

3 → System

Clicking the magnifier  will bring the user to information regarding the system, such as redundancy, available power, and so on. It is also the path to module level monitoring.

The three LEDs are showing the state of each converter.

Example: if any one of the internal converter of the module is in problem, then the led will turn to the corresponding color.

4 → AC out

Clicking the magnifier  will bring the user to all measurements regarding AC Out.

Regardless of the system configuration (1P, 3P), displayed power is the total amount of power fed to the load.

Power is expressed in both KW and KVA, and the Power Factor (PF) is computed.

5 → Gauge

In a 1P output system, the gauge depicts the percentage of power used in VA.

In a “more than 1P” system, the gauge depicts the “worst case,” i.e., if the system is unbalanced, it shows the most loaded phase.

6 → MBP

MBP is configured in the system.

9.8.3 Toolbar



The tool bar is always accessible and provides quick access to the following pages:

- **Events page**

The events icon has the color of the highest priority alarm currently present in the system:

- Green: system healthy, no event present.
- Grey: at least one event is present in the system but not configured as major or minor.
- Orange: at least one minor event present in the system. No major event but other events could be present also.
- Red: at least one major event is present in the system. Other events or minor events could be present.



If more than one event is present, regardless of its level, a counter is present on the icon. It displays the total number of event currently present in the system.

- **Connections**

This brings to digital input and relays status. For configuring these inputs and outputs, it's in the configuration section.

- **Files**

This leads to the file management page. Files such as configuration, update and log download.

- **Parameters**

The parameters page allows user to change every parameter related to the system.

Throughout the browsing, the user can see the following icons:



When accessing a page of depth of two or more (such as module or log page), the user can go back to previous page by clicking “back” icon



Clicking on “Home” icon goes to the home page from any page you are accessing in the interface.



Clicking on “Logout” icon goes to the login page

Note: To know more details, refer to the T2S-ETH with Inview X user manual.

10. Unit - Inserting/removing/replacing

10.1 TSI Inverter Module

- When a new module is inserted in a system, it is automatically assigned the configuration file from the existing modules or from the T2S-ETH.
- When a new module is inserted in a system, it is automatically assigned to the next available address.

10.1.1 Removal

Note: When one or several inverter modules is/are removed, live parts become accessible. Replace module with dummy cover without delay.

Warning: Inverter module is not switched off while opening the handle. The handle only hooks the module to the shelf.

- Step 1.** Use a screwdriver to release the latch of the handle.
- Step 2.** Open the handle and pull the module out.
- Step 3.** Replace with a new module or dummy cover.




Figure 24. Module Removal

10.1.2 Inserting

- Step 1.** Check module compatibility (DC Voltage!).
- Step 2.** Use a screwdriver to release the latch of the handle.
- Step 3.** Open the handle and Push firmly until the unit is properly connected.
- Step 4.** Close the cover and latch in position.




Figure 25. Module Inserting

10.2 T2S-ETH

T2S-ETH is hot-swappable. It can be removed or replaced without affecting the operation of the system. If a new T2S-ETH is inserted in the live system, the modules will automatically configure the system parameters within the T2S-ETH.

10.2.1 Removal

1. Use a small screwdriver to release the latch keeping the T2S in position.
2. Pull the T2S-ETH out.




Figure 26. T2S Removal


10.2.2 Inserting

1. Push the T2S firmly in place until the latch snaps in position.
2. In Inview X, Green LED (OK) will flash for a few seconds and wait until it becomes solid green. Once the LED turns green, the connection is established and the home page appears in Catena screen.
3. If Inview X screen displays any warning message as "Limited or no connectivity":
 - Check the ETH cable connection between Inview X and T2S-ETH.
 - Reset Inview X
 - Reinsert the T2S-ETH in the shelf.


10.3 Inview X

Before mounting the Inview X in the system, route all the required connection cables from the system and place near to the Inview X mounting location.


1. Place the Inview X in the panel sheet.
2. Fix the Inview X in the panel sheet using four screws at the rear side.
3. Connect required connection cables to the Inview X.
4. Place the panel sheet in the system and fix it with screws.




Place the Inview X in the panel sheet



Fix it with four screws



Connect wires and place the panel sheet in the cabinet



Fix the panel sheet with screws

10.4 Fan replacement

The fan's life is approximately 60,000 (Sixty thousand) hours. The inverter modules have fan runtime meters and fan failure alarm. Fan failure can result from the failing fan or driver circuit.



- Let the module rest at least five minutes before initiating work.
- The inverter front cover must be removed. Use a flat screwdriver, release all the four latches on side of the module and remove the front cover.
- Disconnect the fan supply cord and remove the fan.
- Replace with a new fan and connect the supply cord.
- Fix the front cover and make sure all the four latches are locked.
- Insert the module in corresponding slot in the shelf.
- Check the fan for operation.
- Access T2S-ETH and reset the fan run time alarm.




Figure 27. Module Fan Replacement

11. Manual Bypass Operation

- Manual Bypass has to be operated by trained personnel only.
- When system is in Manual Bypass the load is connected to AC main voltage without filtering.
- An MBP Engaged output alarm will occur when the system is in Manual Bypass.
- The Manual Bypass is not possible to operate remotely.
- MBP switch is optional.
- An internal MBP switch must be present to cancel the output phase shift prior to operating a non-CE+T wraparound MBP.

11.1 Pre-requisites

Before engaging the MBP, the following conditions have to be fulfilled and actively checked. Failure to follow this procedure could result in loss of power to Critical Load.

1. The AC Input breaker must be closed.
2. Inverter must be synchronized with commercial power.
 - Use Voltmeter to measure voltage between L1 - commercial and L1 - inverter output.
 - Do same measurement with L2 – L2 and L3 – L3.
 - In all cases, voltage must be less than 20 V.
3. The upstream AC & DC breaker must be correctly sized to accept possible overload, The inverter might be overloaded during MBP procedure, depending on voltage network and output inverter voltage setting and if the AC is supplied by a Gen-set, the minimal required power will be twice nominal power of the inverter.

11.2 Manual Bypass Operation

The Manual Bypass operates via individual switch that creates a bypass from mains input via output AC distribution. Inverter modules are bypassed and possible to disconnect without impacting the load.

Operation is “Make before Break”.

11.2.1 Normal to Bypass, Engage MBP

1. Turn the switch from **Normal** to **Bypass**
(Do not stop at **INTERIM** Position)
2. Turn OFF **DC Input**



Figure 28. MBP Switch


Manual Bypass puts the module in OFF state but doesn't disconnect the DC.
Make sure DC is disconnected before any intervention inside the system.

Warning: Risk of electric shock. Power will be available at AC Input terminal, AC Output terminal, DC Input terminal, and Surge Arresters.

Warning: Always engage MBP on inverter before operating wraparound external bypass.

11.2.2 Bypass to Normal, Disengage MBP

1. Turn switch to **INTERIM** (mid position).
2. PAUSE: Wait until the inverter modules have come to full operation and have synchronized (30-60seconds). The Top-Left LED on each module should be Green prior to proceeding.
3. Rotate the switch to the **NORMAL** position.
4. Turn on DC input.



Note: When systems are operated as DC primary, failure to follow this procedure may result in DC Plant and/or genset overloads.

WARNING

IF ATS (automatic transfer switch) IS INSTALLED UPSTREAM TO SELECT AC SOURCE. MAKE SURE THAT THE ATS SWITCH DOES NOT ALLOW TRANSFER BETWEEN AC SOURCE OUT OF SYNC. THE MAXIMUM ALLOWED PHASE SHIFT IS 10°.

12. EMBS

“See EMBS User Manual” for more information.

13. Final Check

- Make sure that the sub-rack and cabinet is properly anchored to the cabinet/floor.
- Make sure that the sub-rack/cabinet is connected to Ground.
- Make sure that all DC and AC input breakers are switched OFF.
- Make sure all cables are sized and installed according to NEC guidelines and the local authority having jurisdiction.
- Make sure all cables have proper strain relief installed.
- Make sure that all breakers are sized according to the NEC guidelines and the local authority having jurisdiction.
- Make sure that the DC cable polarity is verified and installed according to the DC terminal designations.
- Re tighten all electrical terminations.
- Make sure that no inverter/controller positions are left open.
- Cover empty inverter positions with blanks.
- Make sure that the Remote ON/OFF is appropriately wired according to local regulations.
- Make sure that the point of AC supply meets local regulations.

14. Commissioning

The inverter module DC input breaker acts as a protective device. When the modules are inserted into a system the DC breaker can then be turned ON to activate the DC input of the module.

Installation must be performed by competent qualified employees.

Commissioning and startup must be performed by any personnel who have been duly trained and possess a valid (non-expired) trainee ID certification number.

Contact your CE+T sales representative for more information on training classes. Classes are available for vendors, installers, and service providers.

It is prohibited to perform any insulation test without instruction from manufacturer.

Equipment is not covered by warranty if procedures are not followed.

14.1 Check list

Refer the document “Commissioning Procedure” and available on request.

15. Trouble shooting

15.1 Trouble shooting

Inverter module does not power up:	Check AC input present and in range (AC breakers) Check DC input present and in range (DC breakers) Check that the inverter is properly inserted Remove inverter to verify that slot is not damaged, check connectors Check that module(s) is (are) in OFF state Check for loose terminations
Inverter system does not start:	Check that T2S ETH is present and properly inserted Check remote ON/OFF terminal Check the configuration and setting Check threshold level
Inverter only run on AC or DC:	Check AC input present and in range (AC breakers) Check DC input present and in range (DC breakers) Check the configuration and setting Check threshold level(s)
No output power:	Check output breaker
All OK but I have alarm:	Check configuration file and correct No of modules Download/clear log file
No output alarm:	Check the default time delay (UA “Major Alarm” - 60s, NUA “Minor Alarm” - 30s) Check configuration file
No information on Inview X:	Check that T2S ETH is present and properly inserted Check that the RJ45 cable is connected between T2S ETH shelf and Inview X

15.2 Defective modules

Unless input power is down, all LED's on each module should be green (see section 9.1, page 36). No light, orange light, red or flashing light are abnormal conditions. Collect and record the module information. If no fix can be found, replace the module.

15.2.1 Replacing modules

Refer to section 10.1, page 50 to remove and re-insert modules.

15.2.2 Return defective T2S interface


A T2S totally dark (indication area) or that cannot interface with your laptop are evidence of failure. Proceed as per section 15.2.4, page 59.

15.2.3 Return defective shelf

There are no active components on the TSI shelf. Due to this, failure of the shelf is uncommon. Field replacement of a shelf is complicated and requires a CE+T factory technician to be dispatched to the site. Refer to section 16, page 60 for more information.

15.2.4 Return defective modules

- A repair request should follow the regular logistics chain:
End-user => Distributor or Value Added Reseller => CE+T Power.
- Before returning a defective product, a RMA number must be requested through the <http://my.cet-power.com>. Repair registering guidelines may be requested by email at repair@cet-power.com.
- The RMA number should be mentioned on all shipping documents related to the repair.
- Be aware that products shipped back to CE+T Power without being registered first will not be treated with high priority!
- While returning the defective module, should mention all the details in the RMA document.



16. Service

For Service

- Check Service Level Agreement (SLA) of your vendor. Most of the time they provide assistance on call with integrated service. If such SLA is in place, you must call their assistance first.
- If your vendor doesn't provide such assistance (*) you may call CE+T directly. Toll free Number **1(855) 669 - 4627(**)**

Service is available from 8:00 A.M. to 10:00 P.M. EST, Monday through Friday, except closing periods for holidays or inclement weather.

Major Incidents and Emergency conditions can be invoked for immediate handling of same number or by dropping a mail on customer.support@cetamerica.com (***)

(*) CE+T will redirect your call to your vendor if he has such SLA in place.

(**) Valid in USA and Canada only.

(***) Messages that are not Major Incident or Emergency will be served at the next scheduled working day.

17. Maintenance Task

As maintenance can be performed on live system, all tasks should be performed only by trained personnel with sufficient knowledge on TSI products.

Tasks :

- Identify the site, customer, rack number, product type.
- Download and save the configuration file for back up.
- Check configuration file to be in accordance with operational site conditions.
- Read and save log files for back up.
- Check and analyze log file and if alarm is present.
- Replace dust filter if present. The filter is mandatory in the dusty environment.
- Check module temperature and log value. If the internal temperature is higher than the previous year, determine if this is due to increased load, accumulated dust or reduced airflow. It is common to have a delta of 15°C by 30% of the load between the ambient and the internal temperature. If temperature increases due to internal dust built up, clean the TSI with the vacuum cleaner.
- Clean system (vacuum cleaner or dry cloth).
- Control the inverter mapping (AC Group, DC Group, Address).
- Check load level and record the rate value (print in word document the 4 screen modules information for the 32 modules, the 3 screen for the phases value and the 2 screens for the group AC and DC value)
- Change the configuration file for AC and DC mix mode to check that all TSI work on both power supply.
- Check alarm operation (e.g., redundancy lost, mains failure, DC failure) on dry contact and through SNMP system or web interface.
- Switch OFF AC IN and check alarms.
- Check temperature terminal and temperature wiring. If possible use an infrared camera.
- Read and record value as waveform, power factor, crest factor, THD I from power analyzer.
- Take system picture
- Keep track of reports and provide the end-user with a copy.
- Perform an MBP procedure. This task is not really recommended*, but could be demanded by the site manager.

* It is not recommended because when you perform a By-pass procedure, generally there is no back up on the AC input line, and the load shutdown if mains disappear.

