



Leading Conversion Technology for Power Resilience

INVIEW

Firmware 6.x

User Manual

INVIEW MONITORING & CONTROL DEVICES:

- Manages your Infrastructure
- Informs the user in case of Issues
- Minimises Maintenance Expenditures
- Leverages the possibilities of IoT & Big Data
- Allows to save on your electricity bill with Energy Management



CONTROLLERS FOR BRAVO AND SIERRA MODULES

- Inview Slot
- Inview S
- Inview X & X+
- Inview XC



Copyright ©2025. Construction électroniques & telecommunications S.A.
All rights reserved. The contents in document are subject to change without notice.
The products presented are protected by several international patents and trademarks.
Address: CE+T S.a, Rue du Charbonnage 12, B 4020 Wandre, Belgium
www.cet-power.com - info@cet-power.com

Version 2.5



Table of Contents

1. CE+T Power at a glance.....	7
2. Abbreviations	8
3. Warranty and Safety Conditions	9
3.1 Disclaimer	9
3.2 Technical care	9
3.3 Installation	10
3.3.1 Handling.....	10
3.3.2 Surge and transients	10
3.3.3 Other.....	10
3.4 Maintenance	11
3.5 Replacement and Dismantling.....	11
4. Introduction	12
4.1 Inview Slot	12
4.2 Inview S	12
4.3 Inview X and X+	13
4.4 Inview XC.....	13
4.5 Inview Widget Page.....	14
4.6 Inview Slot, S, X, X+ & XC - Specifications.....	15
4.7 Inview License	16
4.8 Accessories.....	18
4.8.1 MBB (Measure Box Battery).....	18
4.8.2 Measure Box Battery Specifications.....	19
5. Installation	20
5.1 Site preparation.....	20
5.2 Installing - Inview Slot	20
5.3 Mounting - Inview S	20
5.3.1 Panel Mounting	20
5.3.2 Din-rail Mounting	21
5.4 Mounting - Inview X / X+.....	22
5.5 Installing - Inview XC.....	22
5.5.1 Wall mounting	22
5.5.2 Pole mounting	23
5.5.3 Panel mounting	23
5.6 Hardware Connections	23
5.6.1 Inview Slot - Connections	23
5.6.2 Inview S - Connections.....	24
5.6.3 Inview X / X+ - Connections	25
5.6.4 Inview XC - Connections.....	26
5.6.5 MBB (Measure Box Battery) - Connections	27
5.6.6 Output Relay Connections.....	28

5.6.7	Digital Input Connections.....	28
5.6.8	CAN / ModBus (RS485) Pin Details	29
5.6.9	Inview Slot with Bravo 10 and Sierra 10 - System	29
5.6.10	Inview S with Bravo and Sierra - System	30
5.6.11	Inview X / X+ with Bravo and Sierra - System.....	30
5.6.12	Inview XC with Sierra XC - System	31
6.	Overview - Web Interface	32
6.1	Interface Areas	33
6.1.1	Header	33
6.1.2	Home Page.....	34
6.1.3	Widgets.....	35
6.2	Web page Controls	36
7.	Power System Settings	38
7.1	Login.....	38
7.2	Users Management	38
7.2.1	Web Interface - User account	39
7.2.2	LCD Interface - PIN number.....	39
7.3	Site Management	40
7.3.1	Site Description	40
7.3.2	Date and Time Settings	40
7.3.3	Network Settings.....	41
7.4	System Configuration	41
7.4.1	Topology Selection	42
7.4.2	Fallback mode.....	43
7.4.3	Phase Selection	44
7.4.4	AC Output Configuration	44
7.4.5	Converters Configuration	45
7.4.6	DC Configuration	46
7.5	Battery Configuration	46
7.5.1	Measurement Source	47
7.5.2	Battery Disconnect or LVD	48
7.6	Sensors and Actuators.....	48
7.6.1	MBB Configuration	49
7.7	Manual Bypass Configuration	52
7.8	Module Remote ON/OFF	53
7.9	Widgets Configuration	54
7.10	Communication Protocol.....	58
7.10.1	Modbus.....	58
7.10.2	SNMP.....	60
7.10.3	MIB	60
7.11	Cyber Security.....	61
7.11.1	Password Policy	61
7.11.2	Weak Password Alarm.....	61
7.11.3	Password Protection.....	61

7.11.4 Software Downgrade and Reset	61
8. Overview - LCD Interface	63
8.1 Inview Slot - LCD Display	63
8.1.1 LED Indications	63
8.1.2 Menu Structure	64
8.2 Inview S - LCD Interface	65
8.2.1 LED Indications	65
8.2.2 Menu Structure	66
8.3 Inview X / X+ - LCD Interface	67
8.3.1 Menu Structure	68
8.3.2 LED Indications	69
8.4 Inview XC - LED Indications	69
8.5 LCD Interface - Terminology	69
9. Defective Unit	70
9.1 Return Defective Inview	70
10. Trouble shooting and Service	71
11. Annexe 1: Converter - Parameter List.....	72
12. Annexe 2: PLC/Boolean Expression	73
12.1 Overview	73
12.2 Abbreviations used in the Syntax	73
12.3 Use of syntax to access data entries from a monitored device	74
12.4 Use of syntax to access alarms grouped by severity level or severity type.....	74
12.5 Operators & functions.....	75
12.6 Examples of Boolean Expressions for custom PLC data, alarms and relays	76
12.6.1 Create a custom data	76
12.6.2 Create a custom alarm	77
12.6.3 Create a custom relay	79
12.6.4 Simple examples of custom alarms or data	82
13. Annexe 3: Inview - Software Upgrade.....	84
14. Annexe 4: Hardware Replacement.....	86
14.1 Inview Slot, S, X, X+ and XC	86
14.2 Accessories - MBB 60V / MBB 500V.....	87
15. Annexe 5: Wiring Diagrams	88
15.1 Inview Slot with MBB.....	88
15.2 Inview S with MBB	89
15.3 Inview X / X+ with MBB.....	90
15.4 Inview XC with MBB	91
16. Annexe 6: Auxiliary power supply kit	92
16.1 Auxiliary power supply kit with Din Rail	92
16.2 Auxiliary power supply kit - Wiring diagram.....	92

17. Annexe 7: Inview Panel Sheets.....	93
17.1 Inview S - Panel Sheets.....	93
17.2 Inview X / X+ - Panel Sheet.....	94
17.3 Inview XC - Dimensions.....	94

Release Note

Version	Release date (DD/MM/YYYY)	Modified page number	Modifications
1.0	23/04/2021	-	First release of the manual
1.1	27/08/2021	38	Added Remote ON/OFF details
		58 - 59	Added boolean expressions
1.2	28/09/2021	17 & 19	Updated auxiliary power supply kit part number
1.3	16/11/2022	13, 16 & 21	Added License Options, Din-rail mounting procedure and RS485 details
1.4	16/12/2022	44	Added new password policy details
1.5	14/02/2023	55 - 63	Updated section the Annexe 1: Converter - Parameter List
2.0	14/09/2023	-	Updated the manual to Firmware version 6
2.1	28/02/2024	-	Added Inview XC details
2.2	06/06/2024	28	Updated the Sierra XC with Inview XC connections
2.3	14/08/2024	71-82	Updated the PLC/Boolean expression details
2.4	28/04/2025	-	Removed UMB details, added MB500 and Inview X+ details
2.5	16/05/2025	16	Updated the Inview License details

1. CE+T Power at a glance

CE+T Power is your trusted partner in **advanced power solutions** engineered to meet the demands of modern and dynamic industrial applications. With over 60 years of experience in power conversion technology, CE+T Power nurtures the industry with **innovative solutions designed for critical power backup and energy management**.

Our complete range of power solutions includes **modular inverters** (DC to AC), UPS (securing AC loads with batteries), and **multi-directional converters** (inverter, rectifier, and UPS all-in-one). Coupled with our state-of-the-art **monitoring solution**, you have a real energy blender to connect multiple sources of energy seamlessly!

Whether you require **robust backup power solutions**, **energy management solutions**, or a **combination of both**, CE+T Power delivers tailored solutions to meet your specific needs. Our products are **designed with integration in mind**, ensuring **seamless compatibility with other components of your system**. CE+T Power is committed to providing you with the expertise and resources needed to maximize the performance of your power systems.

Thank you for choosing CE+T Power as your partner in advanced power management. Let's power the future together.

2. Abbreviations

AC	Alternating current
AL	Alarm
DC	Direct current
DHCP	Dynamic Host Configuration Protocol
DSP	Digital Signal Processor
ECI	Enhanced Conversion Innovation
EPC	Enhanced Power Conversion
ESD	Electro Static Discharge
ETH	Ethernet
HTTP	HyperText Transfer Protocol
HTTPS	Secure HyperText Transfer Protocol
LAN	Local Access Network
LVD	Low Voltage Disconnect
MBB	Measure Box Battery
MBP	Manual By-pass
MET	Main Earth Terminal
MIB	Management Information Base
N	Neutral
NTP	Network Time Protocol
NT/KO	Not Okay
NUA	Non-Urgent Alarm
PCB	Printed Circuit Board
PE	Protective Earth (also called Main Protective Conductor)
PEK	Power Extension Kit
PWR	Power
REG	Regular
SNMP	Simple Network Management Protocol
TCP/IP	Transmission Control Protocol/Internet Protocol
TRS	True Redundant Structure
UA	Urgent Alarm
USB	Universal Serial Bus

3. Warranty and Safety Conditions*

WARNING:

Except Inview XC, the electronics in the power supply system are designed for an indoor, clean environment.

When installed in a dusty and/or corrosive environment, outdoor or indoor, it is important to:

- Install an appropriate filter on the enclosure door, or on the room's air conditioning system.
- Keep the enclosure door closed during operation.
- Replace the filters on a regular basis.

Important safety instructions, save these instructions.

3.1 Disclaimer

- The manufacturer declines all responsibilities if equipment is not installed, used or operated according to the instructions herein by skilled technicians according to local regulations.
- Warranty does not apply if the product is not installed, used and handled according to the instructions in the manuals.

3.2 Technical care

- This electric equipment can only be repaired or maintained by a “qualified employee” with adequate training. Even personnel who are in charge of simple repairs or maintenance are required to have knowledge or experience related to product maintenance.
- Please follow the procedures contained in this Manual, and note all the “DANGER”, “WARNING” AND “NOTICE” marks contained in this Manual. Warning labels must not be removed.
- Qualified employees are trained to recognize and avoid any dangers that might be present when working on or near exposed electrical parts.
- Qualified employees understand how to lock out and tag out machines so the machines will not accidentally be turned on and injure employees working on them.
- Qualified employees also understand safety related work practices, including those by OSHA and NFPA, as well as knowing what personal protective equipment should be worn.
- All operators are to be trained to perform the emergency shut-down procedure.
- Never wear metallic objects such as rings, watches, or bracelets during installation, service and maintenance of the product.
- Insulated tools must be used at all times when working with live systems.
- When handling the system/units pay attention to sharp edges.

* These instructions are valid for most CE+T Products/Systems. Some points might however not be valid for the product described in this manual.

3.3 Installation

- This product is intended to be installed only in restricted access areas.
- The Inverter System may contain output over current protection in the form of circuit breakers. In addition to these circuit breakers, the user must observe the recommended upstream and downstream circuit breaker requirements as per the local regulations.
- Please use extreme caution when accessing circuits that may be at hazardous voltages or energy levels.
- The modular inverter rack is a dual input power supply. The complete system shall be wired in a way that both input and output leads can be made power free.
- In REG systems, to comply with local and international safety standards the N (output) and PE shall be bonded. The bonded connection between N (output) and PE must be removed once the AC input is connected.
- AC and DC circuits shall be terminated with no voltage / power applied.
- The safety standard IEC/EN62040-1-1 requires that, in the event of an output short circuit, the inverter must disconnect in 5 seconds maximum. The parameter can be adjusted on Inview controller; however, if the parameter is set at a value > 5 seconds, an external protection must be provided so that the short circuit protection operates within 5 seconds. Default setting is 60 seconds.
- The system is designed for installation within an IP20 or IP21 environment. When installed in a dusty or humid environment, appropriate measures (air filtering) must be taken.
- All illustrations in the manual are for general reference.

3.3.1 Handling

- The cabinet shall not be lifted using lifting eyes.
- Remove weight from the cabinet by unplugging the inverters. Mark inverters clearly with shelf and position for correct rebuild. This is especially important in dual or three phase configurations.
- Empty module positions must not be left open. Replace with dummy cover.

3.3.2 Surge and transients

The mains (AC) supply of the modular inverter system shall be fitted with Lightning surge suppression and Transient voltage surge suppression suitable for the application at hand. Manufacturer's recommendations of installation shall be adhered to. Selecting a device with an alarm relay for function failure is advised.

Indoor sites are considered to have a working lightning surge suppression device in service.

- Indoor sites Min Class II.
- Outdoor sites Min Class I + Class II or combined Class I+II. The modular inverter system/rack can reach hazardous leakage currents. Earthing must be carried out prior to energizing the system. Earthing shall be made according to local regulations.

3.3.3 Other

- Isolation test (Hi-Pot) must not be performed without instructions from the manufacturer.

3.4 Maintenance

- The converter system/rack can reach hazardous leakage currents. Earthing must be carried out prior to energizing the system. Earthing shall be made according to local regulations.
- Prior to any work conducted to a system/unit, make sure that AC input voltage and DC input voltage are disconnected.
- Prior to accessing the system or modules, make sure all source of supply is disconnected.
- **CAUTION** – Risk of electric shock. Capacitors store hazardous energy. Do not remove cover until five minutes after disconnecting all sources of supply.
- Some components and terminals carry high voltage during operation. Contact may result in fatal injury.

3.5 Replacement and Dismantling

- ESD Strap must be worn when handling PCBs and open units.
- CE+T cannot be held responsible for disposal of the Inverter system and therefore the customer must segregate and dispose of the materials which are potentially harmful to the environment, in accordance with the local regulations in force in the country of installation.
- If the equipment is dismantled, to dispose of its component products, you must comply with the local regulations in force in the country of destination and in any case avoid causing any kind of pollution.

To download the latest documentation and software, please visit our website at www.cet-power.com

4. Introduction

4.1 Inview Slot

Inview Slot is an advanced monitoring and controller unit for Bravo 10 and Sierra 10 power systems. This product is specially designed in 1U height to accommodate in the converter shelf and reduces the additional space in the cabinet.

The Inview Slot also allows the user to easily access the system information through inbuilt powerful LCD touch screen graphic display. In addition to the touch screen display, the user can also access the system information through the web interface and SNMP protocol.

The Inview Slot interface provides the user to access the configuration and setup files of the modules in the system. Also, it is a controller for DC regulation

Inview Slot can monitor up to 32 inverters/converters and featured with:

- 1.8" LCD touch screen display
- Three LED's to indicate Major alarm, Minor alarm and System status
- Two Digital Inputs
- Two Output Relay contacts
- Records 5000 logs as FIFO



Inview Slot

4.2 Inview S

Inview S is an advanced monitoring and controller unit for Bravo 10, Bravo 25, Sierra 10, Sierra 25 and Flexa 25 power systems. It allows the user to easily access the system information through inbuilt powerful touch screen graphic display. In addition to the touch screen display, the user can also access the system information through the web interface and SNMP protocol.

The Inview S interface provides the user to access the configuration and setup files of the modules in the system. Like Inview Slot, it is also a controller for DC regulation.

Inview S can monitor up to 32 inverters/converters and featured with:

- 2.8" LCD touch screen display
- Three LED's to indicate Major alarm, Minor alarm and System status
- Two Digital Inputs
- Two Output Relay contacts
- Records 5000 logs as FIFO



Inview S

4.3 Inview X and X+

Inview X / X+ is an advanced monitoring and controller unit for **Bravo 10, Bravo 25, Sierra 10 and Sierra 25** power systems. It allows the user to easily view, access the system information through LCD screen graphic display and web interface. The home screen of both LCD and web interface provides a summary of system power, modules, batteries, and events information.

The Ethernet ports in Inview X / X+ allows multiple communication points for remote communication and Web interface. This additional Ethernet port makes it compulsory to use Inview X / X+ with large systems relying on the Power Extension Kit and also when Inview Gateway is required to manage several kinds of CE+T converters.

The Inview X / X+ comes up with easier access to connect accessories such as Measure Box Battery, Smart Battery BMS and so on. Its interface provides the user access to the configuration and setup files of the modules that are connected in the system. It is also a controller for DC regulation.

Inview X / X+ is featured with the following:

- Monitor up to 32 converters, and with Power Extension Kits, it can monitor up to 270.
- 7" LCD touch screen display with LED strip around the screen to indicate Major alarm, minor alarm and system status.
- Two Digital Inputs and two Output Relay contacts.
- Higher Temperature Resistance
- Records 5000 events as FIFO



Inview X



Inview X+

4.4 Inview XC

Inview XC is an advanced monitoring and controller unit especially suited for **Sierra XC 10** power systems. It allows the user to easily access the system information through the web interface and SNMP protocol.

The Inview XC interface provides the user to access the configuration and setup files of the modules in the system. Like the other Inview interfaces, it is also a controller for DC regulation.

Inview XC is featured with the following:


- Monitors up to 32 converters.
- Three LEDs to indicate Major alarm, Minor alarm and System Status.
- Two Digital Inputs and two Output Relay contacts.
- Higher temperature resistance.




Inview XC

4.5 Inview Widget Page

The generic view for the different Inview Slot, S, X and X+ touch screens, as well as in the web interface.



Widget view in Web interface



Widget view in LCD Touch screen - Inview X / X+, S and Slot (from left to right)

4.6 Inview Slot, S, X, X+ & XC - Specifications

Models	Inview Slot	Inview S	Inview X	Inview X+	Inview XC
Modules compatibility	Bravo 10 and Sierra 10	Bravo 25 and Sierra 25			Sierra XC 10 & 16
Display	1.8" resistive touchscreen	2.8" capacitive touchscreen	7" capacitive touchscreen		No (IP65 protected)
Hardware interfaces	1 x ETH*, 1 x RS485, 1 x CAN, 1 x USB	1 x ETH*, 1 x RS485, 1 x CAN, 1 x USB	3 x ETH*, 1 x RS485, 1 x CAN, 2 x USB		1 x ETH*, 1 x RS485, 1 x CAN, 1 x 19 Pin connector
Supported protocols	Modbus RS485, Modbus TCP, SNMP v1, v2C and v3, HTTP/HTTPS				
Digital Input / Output relay	2 / 2				
Accessories	Measure Box Battery (MBB 60V and 500V)				Measure Box Battery (MBB) with external power supply
Buzzer	Yes				No
Mounting	1U Shelf	DIN / Panel / Door	Panel / Door		Pole / Wall / Panel / Door
Power supply	Internal shelf 48 Vdc (40 to 60 Vdc) or External 12 Vdc (10 to 14 Vdc)	External 12 Vdc (10 to 14 Vdc)	External redundant 2 x 48 Vdc (40 to 60 Vdc)	External redundant 2 x 12 Vdc - 24 Vdc - 48 Vdc (12 to 60 Vdc)	Internal power supply 12 Vdc (from Modules)
Power consumption	6 W	5 W	17 W		5 W
Operating Temperature Range	-20 to 50°C	-20 to 50°C	-40 to 65°C		-40 to 65°C
CPU	NXP i.MX 6UltraLite			NXP i.MX 6QuadPlus	NXP i.MX 6UltraLite
CPU cores	1 x ARM Cortex A7			4 x ARM Cortex A9	1 x ARM Cortex A7
CPU frequency	528 MHz			996 MHz	528 MHz
Integrated GPU	No			Yes	No
RAM	512 MB			1 GB	512 MB
eMMC	2 x 4 GB			2 x 8 GB	2 x 4 GB
Dimension (WxHxD)	87 x 42 x 331 mm	180 x 83 x 31 mm	187 x 128 x 54 mm		312 x 71 x 155 mm
Weight	650 g	240 g	725 g		2.5 kg
Part number	T602004110	T602004100	T602004200	T602004220	T602004140

*: 100 Mbps, auto-negotiation


4.7 Inview License

Each Inview Slot/S/X/X+/XC has a standard licence by default and it can be upgraded to any of the below licences. Contact your supplier or CE+T for the latest price.

License Number	License Type	Features
1	Standard (called 'Inview')	<ul style="list-style-type: none"> • Communication with a limited number of CE+T devices: <ul style="list-style-type: none"> ▪ Maximum 32 Sierra/Bravo/Iris ▪ MBB 60V and MBB 500V without limitation • Real Time Monitoring and Configuration via Web Interface, including relay mapping: <ul style="list-style-type: none"> ▪ Access to Inview web interface ▪ Alarms reflecting the system status ▪ Events ▪ Real-Time Data ▪ Access to controls to send manual set points via web interface • System Remote Interaction for data collecting: Modbus read, email alerts, SNMP traps and NTP: <ul style="list-style-type: none"> ▪ Modbus TCP/RS485 Read Only ▪ Email Notification from a certain alarm level (SMTP) ▪ SNMP v1, v2c, v3 Read Only and Traps ▪ NTP Protocol • Cybersecurity Capabilities: <ul style="list-style-type: none"> ▪ Firewall access ▪ https with self-signed /standard certificate • 3 Levels of User Roles: <ul style="list-style-type: none"> ▪ Basic, Expert, Admin roles give access to different parameters ▪ User Role Management via Admin login • Provides basic power management capabilities, including battery regulation (with Sierra modules): <ul style="list-style-type: none"> ▪ UPS for AC loads & UPS for AC and DC loads with Bidirectionality on DC port ▪ Battery Regulation Algorithms: CC-CV, Boost, Temperature Compensation, Battery Test, Battery Disconnect
2	Operation extension	<ul style="list-style-type: none"> • Reporting, configuration and control via Machine-to-Machine Interface: <ul style="list-style-type: none"> ▪ Customized Boolean Expressions for Relay control (PLC) ▪ Data recordings and charts display ▪ Modbus TCP/ RS485 and SNMP Read & Write • Enhanced Cybersecurity Capabilities: <ul style="list-style-type: none"> ▪ RADIUS (Remote Authentication Dial-In User Service) ▪ IEEE 802.1X Standard (DoT.1X) - Authentication with SCEP with automatic certificate renewal ▪ Https connection (custom/official certificate)

3	Equipment extension	<ul style="list-style-type: none"> • Communication with Third Party device: <ul style="list-style-type: none"> ▪ Communication with any interfaced third party device (MPPT, SunSpec modbus inverters, smart batteries, meters...) ◆ May require additional cost due to interfacing service if the device has not been interfaced yet. Interfacing service to be provided by CE+T ◆ Maximum number of devices depends on the device itself • Communication with additional CE+T devices: <ul style="list-style-type: none"> ▪ One or several Power Extension Kits, i.e. communication with more than 32 of Bravo 25 or Sierra 25 converters ▪ Several kinds of modules in a single system
5 (2+3)	Operation & Equipment extensions	<ul style="list-style-type: none"> • Contains all the content of Operation and Equipment licenses
6	Power management extension	<ul style="list-style-type: none"> • Contains all the content of Operation and Equipment licenses • Advanced Battery Management (only with Sierra 25 - 48/277 and Sierra 25 - 380/230): <ul style="list-style-type: none"> ▪ Maximum Discharging Current limitation ▪ State of Charge Operating Range ▪ Top-Off Charge • Tools for PMS Functionalities (only with Sierra 25 - 48/277 and Sierra 25 - 380/230): <ul style="list-style-type: none"> ▪ Grid Interactive converter parameters ▪ Access to converter parameters for AC-out coupling • Power Management System (PMS) functionalities (only with Sierra 25 - 48/277 and Sierra 25 - 380/230): <ul style="list-style-type: none"> ▪ Peak-Shaving ▪ Self-Consumption/Off-Grid: Dispatchable Source Control, AC-out Coupled and Load-Shedding ▪ Forced Import/Export • Scheduling Tool: calendar to configure PMS functionalities
4 (existed before PMS extension)	Customization extension	<ul style="list-style-type: none"> • Contains all the content of Operation, Equipment and Power management licenses • Gives access to scripting: <ul style="list-style-type: none"> ▪ The scripts are developed by CE+T ▪ Only accessible on request after discussion and approval with the Engineering/Pre-sales team ▪ Price depends on the request

To know about the available license options, log in to the web interface, go to *Advanced View > Site > Data > Configuration*, and check the ID DA11 in the Controller section.




4.8 Accessories

4.8.1 MBB (Measure Box Battery)


Measure Box Battery is a unit which monitors the battery parameters such as battery voltage, current, temperature and LVD. In addition it contains extended Digital Inputs and Output Relay contacts.

Measure Box Battery has 60 V and 500 V variants for low and high DC power, respectively.

It is possible to connect up to three MBB 60V and two MBB 500V in parallel.



Measure Box Battery 60V



Measure Box Battery 500V

4.8.2 Measure Box Battery Specifications

Models	Measure Box Battery 60V	Measure Box Battery 500V
VDC measurements	3 Vdc inputs	2 Vdc inputs
VDC range	0 - 60 Vdc	0 - 500 Vdc
IDC measurements	3 ldc inputs	2 ldc inputs
IDC range	0 - 75 mV shunt	
Temperature sensors	2 (type: LM335)	
Output relays	6 0-60 Vdc, 30 W (max 0.5 A)	4 0-60 Vdc, 60 W (max 6 A); 60-250 Vdc, 40 W 0-250 Vac, 1500 VA (max 6 A)
Digital inputs	8 (from free potential contact)	
Communication	CAN	
Power supply	Through Inview or External 12 Vdc input	
Power consumption	1.8 W (6 output relays activated)	2.4 W (4 output relays activated)
Synoptics	1 LED	
Mounting	DIN Rail	
Operating Temperature Range	-20 to 65°C	
Dimension (W x H x D)	160 x 97 x 38 mm	
Weight	240 g	
Part number	T602006000	T602006011


5. Installation

5.1 Site preparation


- All cables should be copper wire and must be rated for min 90°C (194°F).
- All cables must be sized according to the rated current of the Inview / Measure Box Battery and to the customer terminal connection.
- All power and signal cables should be routed properly.

5.2 Installing - Inview Slot


1. Place the Inview Slot and slide into the shelf.
2. Push the unit firmly until the controller rear part is engaged correctly with shelf.
3. Make sure the latch is locked in the shelf.



Place the module & slide into the shelf



Push firmly until module is engaged




Make sure the latch is locked in the shelf

5.3 Mounting - Inview S


Before mounting the Inview S in the system, route all the required connection cables from the system and place near to the Inview S mounting location.

5.3.1 Panel Mounting


1. Place the Inview S in the panel sheet.
2. Lock all the four latches at the rear side of the Inview S in the panel sheet.
3. Connect required connection cables to the Inview S.
4. Mount the panel sheet in the system with screws.




Place the Inview S in the panel sheet



Lock it with four latches at rear



Connect wires and place the panel sheet in the cabinet




Mount the panel sheet with screws


Note: To know about panel sheet dimension and cut-out details, refer “17. Annexe 7: Inview Panel Sheets”, page 93.

5.3.2 Din-rail Mounting


1. Place the two clips on the mounting bracket and fix them with M4 x 8 mm screws and washers.
2. Place the assembled mounting bracket on the Inview S rear side and fix it with self-tapping 2.9 x 9.5 mm screws.
3. Fix the Inview S assembly in the Din-rail.




Place clips on the mounting bracket




Fix it with M4 Screws





Place the mounting bracket assembly on the Inview S



Fix it with 2.9 mm Screws



Take the Inview assembly near to the Din-rail




Fix it on the Din-rail


5.4 Mounting - Inview X / X+

Before mounting the Inview X / X+ in the system, route all the required connection cables from the system and place near to the Inview X / X+ mounting location.


1. Place the Inview X / X+ in the panel sheet.
2. Fix the Inview X / X+ in the panel sheet using four screws at the rear side.
3. Connect required connection cables to the Inview X / X+.
4. Place the panel sheet in the system and fix it with screws.




Place the Inview X in the panel sheet



Fix it with four screws



Connect wires and place the panel sheet in the cabinet



Fix the panel sheet with screws

Note: To know about panel sheet dimension and cut-out details, refer [“17.2 Inview X / X+ - Panel Sheet”](#), page 94


5.5 Installing - Inview XC

Before mounting the Inview XC in the system, route all the required connection cables from the system and place them near the Inview XC mounting location.

Note: To know about Inview XC dimensions and hole details, refer [“17.3 Inview XC - Dimensions”](#), page 94.

5.5.1 Wall mounting

- Clean the wall surface.
- Lift up and hold the controller in position and mark the holes.
- Drill holes on the marked points.
- Fix the controller on the wall using the screws.



5.5.2 Pole mounting

Use pole mounting kits to mount the Inview XC on a pole. We suggest using the PK-121 Pole Mount Kit from Polycase (with a rail length of 305 mm) ([link](#)), or any other pole mounting kit could be used. Refer for the fixations' hole spacing.

5.5.3 Panel mounting


- Place the Inview XC in the panel sheet.
- Fix the Inview XC in the panel sheet using four screws at the rear side.
- Connect required connection cables to the Inview XC.
- Place the panel sheet in the system and fix it with screws.

5.6 Hardware Connections

This section describes the hardware connections of the Inview controllers and measure boxes (MBB). For further information about system interconnections, refer to the converters' user manuals (Sierra, Bravo, Flexa,...) available on www.cet-power.com.

5.6.1 Inview Slot - Connections

Inview Slot has an ETH port and USB at the front. Output relays, digital inputs, CAN and power connections are present at the rear side of the Inview Slot connected shelf.




5.6.1.1 Inview Slot - Front connections

- **LAN port** is used for network connectivity and user can access the system information in the Web Interface. The default static IP address is $10.250.250.1/24$ (the "/24" indicates the Subnet mask address: 255.255.255.0)
- **USB port** is used for internal factory purpose.


5.6.1.2 Inview Slot - Shelf rear connections

- **Digital Inputs (D1 and D2):** Two digital inputs are available for customer connections.
- **Output Relays (K1 and K2):** Two output relays are available and can be used for Major and Minor Alarms.
- **CAN Modbus RTU (RS485) port** is used to establish communication between Inview Slot and accessories. It also provide the +12 Vdc power to **one** Measure Box Battery. To know about RS485 pin details, refer to the section 5.6.8, page 29.
- **iso CAN terminal** is used to establish CAN communication.
(Note: This new CAN feature is available in the PCBs purchased in / after 2025 only)
- **Power:** The redundant external auxiliary +12 Vdc and the power consumption is 5W. By default, Inview Slot takes power from DC bus. If DC is not present, it takes +12 V from external Auxiliary power supply converter (AC to DC).



5.6.2 Inview S - Connections

Inview S is composed of multiple network ports, digital inputs and Output Relay contacts which are present at the rear side of the product.




- **CE+T COM** port is dedicated to establish connection between Inview S and converters.
- **ETH** () port is used for network connectivity and user can access the system information in the Web Interface and SNMP. The default static IP address is 10.250.250.1/24 (the "/24" indicates the Subnet mask address: 255.255.255.0)
- **CAN / iso RS485** port is used to establish communication between Inview S and Measure Box Battery. To know

about RS485 pin details, refer to the section 5.6.8, page 29. It also provides the +12 Vdc power to three MBB 60V or two MBB 500V which are connected in series.

- **USB port** is used for internal factory purpose.
- **Digital Inputs (D1 and D2):** Two digital inputs are available for customer connections.
- **Output Relays (K1 and K2):** Two output relays are available and it is used for Major and Minor Alarms.
- **Power:** +12 Vdc is required for powering the controller and the power consumption is 5W. (CE+T can provide auxiliary power supply converter (48 to 12 Vdc). Part number is **T602004120**).

5.6.3 Inview X / X+ - Connections

Inview X / X+ composed of multiple network ports and inbuilt free potential contacts.




- **CE+T COM** port is dedicated to establish connection between Inview X / X+ and converters.
- **ETH** ports are used for network connectivity, and user can access the system information through the web interface.
 - **ETH Front:** DHCP server, providing access to the configuration at URL <https://inview.local> or <https://10.250.252.1>
 - Intended for direct connection of a laptop computer.
Warning: Do not connect this port to the network, as it might interfere with other DHCP servers.
 - **ETH1:** Main network interface
 - Default static IP address: 10.250.250.1/24
 - It can be configured to other static addresses or as a DHCP client in a web-based configuration interface
 - **ETH2:** Secondary network interface
 - It is dedicated to CE+T accessories like Inview Gateway and do not connect to the network
- **CAN MB** port is used to share the system information to the Measure Box Battery. It also provides the +12 Vdc power to three MBB 60V or two MBB 500V which are connected in series. To know about pin details, refer to the section 5.6.8, page 29.
- **iso CAN** is used for CAN communication.
- **RS485** is used for Modbus communication.
- **USB port** is used for internal factory purpose.
- **Digital Inputs (D1 and D2):** Two potential free Digital Inputs are available for customer connections.
- **Output Relays (K1 and K2):** Two output relays are available and can be used for Major and Minor alarms.

- **Power:**
 - +48V supply is required to power up the Inview X.
 - +12V, +24V or +48 are required to power up the Inview X+.
 - Two terminals are available for redundancy purposes. Note that an alarm (AL100) is monitoring the use of that dual source and should be disabled in case only one of those is used.

5.6.4 Inview XC - Connections

- **CE+T COM** port is dedicated to establish connection between Inview XC and converters.
- **ETH port:** used for network connectivity and user can access the system information in the Web Interface and SNMP. The default static IP address is 10.250.250.1/24.
- **iso CAN/ RS485 ports:** for Modbus RTU and CAN communication. This port should be used for the communication with the Measure Box Batteries. An external power supply is needed for the Measure Box Battery. To know about the pin details, refer to the following figure.
- An “Others” port that comprises:
 - Digital inputs (D1 and D2): Two potential free Digital Inputs are available for customer connections.
 - Output relays (K1 and K2): Two output relays are available and can be used for Major and Minor alarms.
 - An additional iso CAN for CAN communication.

For Inview XC, IP65 rated NLINK0 connectors must be used. Refer to the below picture for Inview XC connectors' pin details.



Note: To solder pins together on the Inview XC side of the 19 pin connector, use a magnifier to view the pin numbers. The numbering corresponds to the pin details given here above.


5.6.5 MBB (Measure Box Battery) - Connections

MBB is composed of multiple digital inputs and analog outputs.

- **Voltage (V1 to V3)** is used to monitor the voltage of DC. Ensure the polarity while wiring.
 - V1: common DC 48V voltage
 - V2: string 1 monitoring
 - V3: string 2 monitoring (Not available in MBB 500V)

5.6.8 CAN / ModBus (RS485) Pin Details

Pin Number	Name	Description
1	CAN_H	CANH pin for CAN protocol
2	CAN_L	CANL pin for CAN protocol
3	GND_Can	Ground pin for CAN protocol
4	ModBus_B	ModBus B through serial port
5	ModBus_A	ModBus A through serial port
6	GND	Ground pin for MBB power supply
7	+12 VDC	+12 VDC for MBB power supply
8	GND_ModBus	ModBus ground




5.6.9 Inview Slot with Bravo 10 and Sierra 10 - System

In Bravo 10 and Sierra 10 systems, the Inview Slot and Measure Box Battery should be connected as per the following:

1. Connect “CAN Modbus RTU (RS485)” port in Inview Slot and “CAN1” port in MBB 60V and MBB 500V. **(Note: MBB is not mandatory for Bravo Systems)**
2. Connect power to Inview Slot and MBB from auxiliary power supply kit.

System with Inview Slot and MBB




For more information about wiring refer “15.1 Inview Slot with MBB”, page 88.

5.6.10 Inview S with Bravo and Sierra - System

In Bravo and Sierra systems, the Inview S and Measure Box Battery should be connected as per the following:

1. Connect “RJ45” port in shelf and “CE+T COM” port in Inview S using RJ45 straight cable.
2. Connect “CAN / iso RS485” port in Inview S and “CAN1” port in MBB 60V and MBB 500V.
(Note: MBB is not mandatory for Bravo Systems)
3. Connect power to Inview S and MBB from auxiliary power supply kit.

System with Inview S and MBB




For more information about wiring refer “15.2 Inview S with MBB”, page 89.

5.6.11 Inview X / X+ with Bravo and Sierra - System

In Sierra system, the Inview X / X+ and Measure Box Battery should be connected as per the following:

1. Connect “RJ45” port in shelf and “CE+T COM” port in Inview X / X+ using RJ45 straight cable.
2. Connect “CAN MB” port in Inview X / X+ and “CAN1” port in MBB 60V / MBB 500V.
(Note: MBB is not mandatory for Bravo Systems)
3. Connect 48 V supply to Inview X / X+ from AC to DC adapter and Battery.

System with Inview X / X+ and MBB




For more information about wiring refer “15.3 Inview X / X+ with MBB”, page 90.

5.6.12 Inview XC with Sierra XC - System

In Sierra XC module, the Inview XC should be connected as per the following:

1. Connect “COM” port in Sierra XC System and “CE+T COM” port in Inview XC using RJ45 straight cable.
2. Connect “CAN ISO RS485” port in Inview XC and “CAN1” port in MBB 60V and MBB 500V.
(Note: Sierra XC provides power to Inview XC only and not to MBB. An external power supply is required to power up the MBB)
3. Connect power to MBB from auxiliary power supply kit

System with Inview XC and MBB




For more information about wiring refer “15.4 Inview XC with MBB”, page 91.

6. Overview - Web Interface

The web interface of all the Inview controllers is the same. The Inview web interface allows the user to interact with system, access, configure and modify the system parameters.


The below tree provides an overview of the menu structure in the web interface.

Note: Widgets varies depending upon the topology selection.




6.1 Interface Areas

- 1 → Header
- 2 → Home Page



6.1.1 Header




The icons on the header provide quick access to the corresponding pages.


- 1 → **Home:** Clicking on **INVIEW** logo goes to the home page from any page you are accessing in the interface.
- 2 → Display the date, time and site name of the system.
- 3 → **Configuration:** Click on  to toggle between Configuration and Widget or Dashboard page.
- 4 → **Alarms:** Clicking on  goes to the Alarm page, where active alarms and last events are listed.
- 5 → **Reporting:** Clicking on  goes to Reporting page, where Data records and Site details are available.
- 6 → **Administration:** Clicking on  goes to the Administration page and provides access to many action pages such as User management, Software update, Configuration files, Reports, References, Languages selection, Support package, Time management, Events log and Licensing.
- 7 → **User Context:** Clicking on  provides the information of login account such as Basic, Expert or Admin, Quick Links to Save Configuration and reboot controller, Website links to download software and documents, Device and network information, Change Password and Logout.

6.1.2 Home Page

The default home page is Widgets to display system information briefly. On the Widgets home page, a maximum of 20 widgets can be configured. To know about configuration, refer to the section 7.9, page 54.




Clicking on any widget displays the corresponding details on right side of the page.



6.1.3 Widgets

The Inview widgets are identical for the web interface and LCD touch screens. The flexible view can be configured depending on the system topology with the following types of widgets:




Source and Load are the different convention signs used for the different assets. The conventions of the different assets are listed in the below table. Based on the type of asset, the widget icon is displayed on the home page.

S.No	Widget	Convention Type	Power Supplied	Power Received
1	Grid	Source	Positive	Negative
2	Genset	Source	Positive	Negative
3	Battery	Load	Negative	Positive
4	DC Source	Source	Positive	Negative
5	Solar	Source	Positive	Negative
6	AC Load	Load	Negative	Positive
7	DC Load	Load	Negative	Positive


6.2 Web page Controls

Placing or clicking on it performs the corresponding action.

Controls	Description
	Filters: Page displays depending upon the filter selection.
	Page changes to edit mode and the user can change the parameters. If any parameter value is changed, the edit icon changes to modification icon and displays the list.
	Rename the parameter name.
	Select the corresponding parameter to either display or not on the Dashboard tab of the Advanced View page.
	On-Board help: Provide a short description to help to know about the corresponding parameters.
	Page or section expands.
	Page or section collapse.
	Particular section opens in a new tab.
	Particular section open as a pop-up.
	Drop down list – more options are present.
	Delete / Clear the corresponding parameter.



Note: Filter, Edit, Rename and Dashboard icons are present at right side of the web page.

Controls	Description
	<p>Modifications list: It appears at right side of the “Advanced View” page. This list helps the user to overview the changes and can apply the required parameters.</p> <p>Apply: Clicking on “APPLY” button, the controller accepts all the parameter changes in the modifications list.</p> <p>Apply and Save: Clicking on “APPLY AND SAVE” button, the controller accepts all the parameter changes in the modifications list and saves them in the configuration file.</p> <p>Dismiss All: Clicking on “DISMISS ALL” button, the controller rejects all the parameter changes in the modifications list.</p> <p>Clicking on  button, the controller rejects only the particular modification from the list.</p> <p>Note: The number on the icon indicates the number of modifications in the list.</p> 

7. Power System Settings

Once system is powered on, the Inview Slot, S, X or XC is up and ready for operation. Configuration and other parameters can be changed using the web interface. Perform the following procedure to configure the system through web interface.

7.1 Login


Open the web browser, type the default IP address **10.250.250.1** in the address field and press enter.

Note: Use any of the latest web browsers: Google Chrome, Mozilla Firefox, Safari, or Microsoft Edge.

Inview Slot, S, X and XC have three login – Basic, Expert and Admin. All three login is password protected.

The default password for all three logins is “1234”. It can be modified, refer section 7.2.1, page 39.


An auto-logout feature is available to avoid a user being connected all the time. When no action is performed for more than 10 minutes, the session will expire and goes to the login screen.



7.2 Users Management

Users page provides the access to create and modify the user accounts for web interface and PIN modification for LCD interface.

Go to [Administration > Users](#).



User name	Role		
Admin	Admin	PASSWORD	DELETE
Expert	Expert	PASSWORD	DELETE
Basic	Basic	PASSWORD	DELETE
user1	Basic	PASSWORD	DELETE

Touch screen pin number
Edit embedded touch screen pin number.
EDIT PIN

7.2.1 Web Interface - User account


Users can create up to **ten** accounts for web interface and assign role as Admin, Expert, or Basic.

- **Basic** – User can only view the parameters and download the files. Advanced parameters are hidden by default and can be displayed via a tick box.
- **Expert** - User can access and modify all the applicable parameters, and can change their own password. Advanced parameters are hidden by default but can be displayed via a tick box.
- **Admin** – User can access, modify all the applicable parameters, and manage user accounts. All parameters are displayed by default (**Note: The manufacturer created *Admin account* cannot be deleted**)

Note: The feature of creating and editing user account is available only in Admin privilege.

- **Creating a new user account**

- In Users page, Click on “+ADD” button. A pop window appears with the title “Add a new user.”
- Enter an appropriate user name and assign a role from the drop down list as Basic or Expert.
- Enter a new password, type the same password for confirmation, and then click **ADD** button. The password length should be at least eight characters.



- **Editing the existing user account**

In the Users page, choose a user account which you like modify.

- Modify the privilege from the “**Role**” drop-down list as Expert or Basic.
- Click on “**PASSWORD**” button to edit existing password.
- Click on “**DELETE**” button to remove the user account.


7.2.2 LCD Interface - PIN number

Inview Slot, S, X and XC LCD interface do not have any user account; the user can view the system details and cannot modify the parameters. The LCD interface is protected with the PIN during any action request.

The default PIN is 1234.

- **Editing the LCD PIN number**

- Select [Administration > Users](#).
- In users page, Click on “**EDIT PIN**” button below the “Touch screen pin number”.
- Enter a new pin, type the same for confirmation, and then click **OK**. The pin should be four characters.




7.3 Site Management

7.3.1 Site Description

Go to [Advanced View](#) > [Site](#) > [Description](#).

Enter the Site details such as *Site description*, *Location* and *Contact details*.




ID	NAME	VALUE
Site Information		
DE1	Site Number	1
DE2	Site Name	CE+T
DE3	Short Description	-
DE4	Info	none
Custom Description		
DE5	Description	undefined
DE6	Reference	undefined
Contact		
DE7	Contact Name	-

7.3.2 Date and Time Settings

Go to [Advanced View](#) > [Administration](#) > [Time Management](#).

Choose any one option from the below.

- **Update with local time:** Inview read the laptop time during the configuration and adapt that time.
- **Update with NTP:** Inview Internal clock synchronizes with the server time.




Local time: 25/08/2023 18:27:49
Update controller internal clock based on system parameters (manual or NTP).

7.3.3 Network Settings

Go to [Advanced View](#) > [Site](#) > [Configuration](#)

Enter the network details such as *IP address, Firewall settings, NTP time, web server*, and applicable parameters.




The screenshot shows the Inview interface in Advanced View. The left sidebar shows a tree view with 'SITE #1' selected. The main content area displays the 'Network' configuration table. The 'Configuration' menu item is highlighted in the top navigation bar.

ID	NAME	VALUE
CF1	DHCP Enabled	False
CF2	IP Address If Static	192.168.20.31
CF3	Subnet Mask If Static	255.255.255.0
CF4	Default Gateway If Static	192.168.20.11
CF5	DNS If Static	8.8.8.8
CF6	DNS 2 If Static	-
Firewall		
CF350	Allow ICMP	True
CF351	Allow Debug Connection	True
CF352	Allow Http	True
CF353	Allowed Ip Source by Mqtt Broker	-
Wifi		
CF390	Activation	Disabled

7.4 System Configuration

To configure the converter systems, In Advanced View, go to [Site](#) > [Energy System](#) > [Converter System](#) > [Configuration](#).




The screenshot shows the Inview interface in Advanced View. The left sidebar shows a tree view with 'ENERGY SYSTEM #1' selected. The main content area displays the 'System' configuration table. The 'Configuration' menu item is highlighted in the top navigation bar.


ID	NAME	VALUE
CF1	Topology	UPS for AC loads
CF6	Number Of Phases	3
CF41	Enable Full Remote Control of Converters (Advanced)	True
CF1047	Triangle mode (Advanced)	0
CF1049	Start without supervision (Advanced)	1
CF1073	Lvd mode (Advanced)	0
CF1098	Sleep mode (Advanced)	0
CF1101	Enable Power Save Mode on DC (Advanced)	False

7.4.1 Topology Selection

In Advanced View, go to [Site](#) > [Energy System](#) > [Converter System](#) > [Configuration](#) > [System](#). In System section > ID CF1, select the topology from the drop-down list based upon the system design.



After selecting the topology, scroll down to [DC](#) > [Modes](#) section on the same page and set the ID CF1071 to “0” or “1” as per in the following table.



Topology CF1	Supported Modules	Input	Output	Parameter ID CF1071	Parameter ID CF1066	Parameter ID CF1067	Parameter ID CF1074
Inverter (REG DC / AC only)	Bravo 25 and 10	DC	AC load	0	NA	NA	NA
Inverter with AC Input (EPC mode)	Bravo 25 and 10	AC and DC	AC load	0	NA	NA	NA
UPS for AC loads	Sierra 10, 25 and XC	AC and DC	AC load and battery charging	1	Fall back mode 1	Fallback mode 1	Fallback mode 1
UPS for AC and DC loads	Sierra 10, 25 and XC	AC and DC	AC & DC load, and battery charging	1	Fallback mode 2	Fallback mode 2	Fallback mode 2
Rectifier	Sierra 10, 25 and XC	AC and DC	DC Load and battery charging	1	Fallback mode 2	Fallback mode 2	Fallback mode 2

7.4.2 Fallback mode

This mode will be activated when the modules lose communication with Inview. There are two modes available depending on the kind of system.

Fallback mode 1:

- **CF1 Topology:**
 - UPS for AC loads
- **CF1066 Charging Voltage:**
 - Configure the voltage required on the DC port in fallback mode. Since the modules do not calculate temperature compensation once communication between the Inview controller and the module is lost. Consider the float voltage at the worst operating scenario.
- **CF1067 Charging Power:**
 - Maximum charging power is required for batteries in fallback mode. Set it according to the datasheet of the connected battery manufacturer.
- **CF1074 Max VDC Increment:**
 - By default, set it to 0. It doesn't have to be used for UPS for AC loads.

Fallback mode 2:


- **CF1 Topology:**
 - UPS for AC & DC loads or Rectifier is set
- **CF1066 Charging Voltage:**
 - Configure the voltage required on DC port in fallback mode. Since the modules do not calculate temperature compensation once communication between the Inview controller and the module is lost. Consider the float voltage at the worst operating scenario.
- **CF1067 Charging Power:**
 - Set the charging power to the maximum power required for charging the battery + Maximum power required for the connected DC load. If the power limit is unknown, set this value to the maximum power capacity of the system so that the DC loads are powered up at any time.
- **CF1074 Max VDC Increment:**
 - Voltage increment is used to recharge the battery in cV/min. Ensures the battery's maximum charging power is limited in fallback mode.
 - If the voltage has to increase rapidly, you can change this value. For example, configuring it to '6' will increase the DC port voltage to a maximum of 3.6V per hour.

7.4.3 Phase Selection

To configure the Single, Dual or Three phase of the system, In Advanced View, go to *Site > Energy System > Converter System > Configuration*.

In the System Section > ID CF6, enter the number of phases based upon the system input/output power.

(Note: while configuring the AC phases, all the converters should be in OFF mode)



ID	NAME	VALUE
CF1	Topology	UPS for AC loads
CF6	Number Of Phases	3
CF41	Enable Full Remote Control of Converters (Advanced)	True
CF1047	Triangle mode (Advanced)	0


7.4.4 AC Output Configuration

To configure AC output parameters, In Advanced View, go to *Site > Energy System > Converter System > Configuration*.

In the AC Outputs section, enter the values for the corresponding parameter ID:

- ID CF121: enter the number of converters configured for phase 1 (Installed power)
- ID CF122: enter the number of converters redundant for phase 1 (Available power)
- ID CF122: enter the phase shift degree for phase 1
- Similarly, enter the values for phase 2 and 3
- ID CF1016: enter the nominal frequency

(Note: while configuring the AC phases, the converter should be in OFF mode)



Phase	Parameter ID	Parameter Name	Value
Phase 1	CF121	Configured Converters	2
	CF122	Redundant Converters	0
	CF123	Nominal Phase Shift (degree) (Advanced)	0
Phase 2	CF141	Configured Converters	2
	CF142	Redundant Converters	0
	CF143	Nominal Phase Shift (degree) (Advanced)	120
Phase 3	CF161	Configured Converters	4
	CF162	Redundant Converters	0
	CF163	Nominal Phase Shift (degree) (Advanced)	240

7.4.5 Converters Configuration

If the system has more than one converter, it is better to start configuring with one converter on each phase.


1. Insert only one converter in the first phase of the system.

Go to [Advanced View](#) > [Site](#) > [Energy System](#) > [Converter System](#) > [Converter](#) > [Control](#).

(Note: while assigning the phases of the converter, its AC output must be in OFF)


- I) Execute the ID CT12, to turn off the converter
- II) In the ID CT2, type "1" to set the converter ID and in the ID CT13 as "1" to assign phase 1
- III) After setting the values, click the  icon to execute that command

In this page, you can turn on/off the module or AC output and DC port of the module.



ID	NAME	EXECUTE
CT1	Blink	
CT2	Set Id	1
CT11	Turn On	
CT12	Turn Off	
CT13	Set Converter AC Phase	2
CT15	Reset Fan Life Elapsed Alarm	

To get an overview of the converter details, go to [Site](#) > [Energy System](#) > [Converter System](#) > [Converter](#) > [Dashboard](#).



AC input	DC	AC output
Voltage: 245.4 V	Voltage: 54.2 V	Voltage: 230.8 V
Current: 1.1 A	Current: -2.1 A	Current: 1.6 A
Frequency: 50.0 Hz	Active power: -0.12 kW (-4.8 %)	Frequency: 50.0 Hz
Active power: 0.24 kW		Active power: 0.38 kW
		Apparent power: 0.38 kVA

In this page also you can modify the converter ID and Phase number.

Other Features:

- **Blink LED:** Clicking on “BLINK LED” button, the corresponding converter LED's blink for 6 seconds. It helps to identify the converter in the system and also the assigned phase of the converter.
- **Turn Off:** Clicking on “TURN OFF” button, the corresponding converter will be turned OFF and generates an alarm in events page as converter off.
- **Set new fan installed:** Clicking on “SET NEW FAN INSTALLED” button, the corresponding converter “Module fan replacement” due will be reset to 2556 days (7 years).

(Note: Do not click this button, until a new fan is replaced inside the converter.)

2. If it is a single-phase system, insert the remaining converters and set module ID and assign them to phase 1.


Perform the following procedure for the multiphase system

3. Insert the second converter in phase 2, and set the Converter ID as “2,” and assign it “Phase 2”
4. Insert the third converter in phase 3, and set the Converter ID as “3,” and assign it “Phase 3.”
5. Repeat the process for remaining converters by adding one converter in each phase.
6. After configuring all the converters, turn ON all the converters.
To turn on all the converters, go to *Advanced View > site > Converter System > Control and execute CT41 parameter.*

7.4.6 DC Configuration

Go to *Advanced View > Site > Energy System > DC System > Configuration.*

In the DC Bus section, set the parameters depending upon the DC voltage. The below page is configured to 48 Vdc.



7.5 Battery Configuration

The battery page provides access and configures battery parameters such as battery characteristics, LVD, temperature compensation, boost charging, and test.

Battery configuration page is applicable only for the following topology designed system.


- UPS for AC loads
- UPS for AC and DC loads

Make sure the ID **CF1071** is set as “1” to configure Sierra converter. (Access to CF1071: *Advanced View > Site > Energy System > System > Configuration > DC > Modes*)

Go to *Advanced View* > *Site* > *Energy System* > *DC System* > *Configuration*.

In the Battery section, enter the details of the battery connected to the system such as Battery Characteristics, Autonomy, float voltage, Current limitation, Temperature, Temperature compensation, Boost and Test.

Note: In this page, the parameters are configured with default values. While modifying the parameters, it is recommended to enter the values as per the system DC voltage and battery datasheet.




ID	NAME	VALUE
CF90	Presence	True
Measurement Source		
CF100	Voltage (Advanced)	Autodetected
CF101	Current (Advanced)	Single shunt
Characteristics		
CF102	Type	Lead-Acid
CF103	Number of Cells	24
CF104	String Capacity	100 Ah
CF105	Number of Strings	3
Autonomy		
CF106	Peukert Number	1.00
CF107	Max Depth of Discharge for Estimation	100.00
Temperature alarms		
CF121	Alarm Low Threshold	5.0 °C
CF122	Alarm High Threshold	40.0 °C
CF123	Alarm High Hysteresis	10.0 °C

7.5.1 Measurement Source

Select any one option for battery voltage and current based upon the battery source in the ID CF100 and CF101, respectively.

- *Auto Detected*: It detects automatically based upon the voltage and current measurement
- Select *“Single probe”*, if MBB measures the DC values
- Select *“Modules”*, if MBB is not installed
- Select *“Smart Batteries”*, if BMS of the battery measures the DC values




ID	NAME	VALUE
CF90	Presence	True
Measurement Source		
CF100	Voltage (Advanced)	Autodetected
CF101	Current (Advanced)	Single Probe
Characteristics		
CF102	Type	Lead-Acid
CF103	Number of Cells	24
CF104	String Capacity (ampere-hour)	100
CF105	Number of Strings	3
Autonomy		
CF106	Peukert Number	1.00
CF107	Max Depth of Discharge for Estimation	100.00

7.5.2 Battery Disconnect or LVD

The LVD in the CE+T system works as bistable only, and it prevents batteries from discharging beyond the threshold voltage. It is installed in-line between the load and the battery. On this page, the parameters are configured with default values. Users can modify it as per the LVD installed in the system.

Go to [Advanced View](#) > [Site](#) > [Energy System](#) > [DC System](#) > [Configuration](#).

In the *Battery Disconnect* section, enter the details of LVD connected to the system.



ID	NAME	VALUE
CF301	Presence	False
CF302	Inhibit (Advanced)	False
CF312	Closing Delay (second) (Advanced)	60
CF313	Opening Delay (second) (Advanced)	15
Voltage Too Low		
CF310	Enabled (Advanced)	True
CF311	Threshold (volt) (Advanced)	46.00
Temperature Too High		
CF321	Enabled (Advanced)	False
CF322	Disconnect Threshold (degree Celsius) (Advanced)	80.00
CF323	Reconnect Threshold (degree Celsius) (Advanced)	65.00


Refer to the section “Relay Configuration”, page 50 for further LVD bistable relay/shunt settings.

7.6 Sensors and Actuators

The Sensors and Actuators page contains details of external devices such as MBB 60V / MBB 500V, which are connected through CANBUS, Ethernet or RS485.

Go to [Advanced View](#) > [Site](#) > [Sensors and Actuators](#) > [Dashboard](#) and set the ID as “MBB -1”.

Note: If a new MBB is replaced, clear the old MBB from the list by clicking “Clean Equipment Inventory”.



Dashboard

BLINK LED MEASURE BOXES CONFIGURATION

Id	I1	I2	I3	V1	V2	V3	T1	T2
MBB-1	-5.8	-0.6	-0.9	53.9	-0.0	0.0	230 °C	230 °C


Digital inputs

D2	D3	D4
Open	Open	Open

Relays


K1	K2	K3
Not Energized	Not Energized	Not Energized

To clear the old MBB 60V / MBB 500V, go to *Advanced View > Site > Control*, scroll down to the *Inventory* section. In the ID CT61 (Clean Equipment Inventory), click the  icon to clear it from the list.




7.6.1 MBB Configuration

Before configuring MBB, go to *Advanced View > Site > Energy System > DC System > Configuration > Battery* and in the *Measurement Source* section, make sure the ID CF100 is set to “Single probe” and ID CF101 to “Single shunt”.




To configure MBB, go to *Advanced View > Site > Sensors and Actuators > Configuration*.

1. **Voltage section:** select an option for the V1, V2 and V3 from the drop-down list in the ID CF101, CF106, and CF111, respectively.



- **dc1_Load**: to measure voltage of DC load
- **dc1_Battery**: to measure the voltage of battery
- **dc1_BatteryMidPoint**: to measure the DC voltage between the batteries midpoint by using V2 and V3


2. **Current section**: select an option for the I1, I2 and I3 from the drop-down list in the ID CF201, CF206 and CF211, respectively.



ID	NAME	VALUE
CF201	Mode	dc1_Battery
CF202	Rating Amps (ampere)	
CF203	Rating mVolt (millivolt)	
CF206	Mode	
CF207	Rating Amps (ampere)	324
CF208	Rating mVolt (millivolt)	50
CF211	Mode	
CF212	Rating Amps (ampere)	324
CF213	Rating mVolt (millivolt)	50

- **dc1_Load**: to measure the current of DC load
- **dc1_Battery**: to measure the current of battery
- Enter the corresponding rating values of shunt

3. **Temperature section**: select an option for the T1 and T2 from the drop-down list in the ID CF301 and CF306, respectively.



ID	NAME	VALUE
CF301	Mode	dc1_Battery
CF302	Calibration Offset (degree Celsius)	0.0
CF306	Mode	
CF307	Calibration Offset (degree Celsius)	0.0

- **dc1_Battery**: to measure the temperature of battery
- **dc1_Ambient**: to measure the ambient temperature of battery

4. **Relay Configuration**: The MBB has six (MBB 60V) and four (MBB 500V) relays and configured as below:


- K1 and K2 are configured to Minor and Major alarms if used.
- K3 and K4 can be configured to any desired alarms or digital inputs if used (not applicable for MBB 500V)

Example: Assigning a relay to the digital input

- Go to K3 relay and select the following options
- ID CF411: select the mode as “Custom”
- ID CF412: select the Default state as “Energized” or “De-energized”
- ID CF413: enter the formula as “@(sa1_data501)”


(Sa1: Sensors and Actuators, data501: Data section, Digital input D1 (DA501))

- After selecting the options, click “APPLY AND SAVE” in the modification list



ID	NAME	VALUE
K1		
CF401	Mode	GlobalMajor
CF402	Default State	De-energized
K2		
CF406	Mode	GlobalMinor
CF407	Default State	De-energized
K3		
CF411	Mode	Custom
CF412	Default State	De-energized
CF413	Boolean Expression	@(convs1_a1301)
K4		
CF416	Mode	Custom
CF417	Default State	De-energized
CF418	Boolean Expression	@(da101)<43


- K5 and K6 are configured to latch or non-latch LVD, if used
 - Relay section:** select an option for K5 and K6 from “Mode” drop down list
 - For latch LVD, select the ID CF421 as “dc1_LvdLatchClose” and CF426 as “dc1_LvdLatchOpen” or vice versa, but must not assign the same value for both relays.
 - For non-latch LVD, select the ID CF421 as “dc1_Lvd”
 - Select Default State as “De-energized”




ID	NAME	VALUE
K5		
CF421	Mode	Custom
CF422	Default State	
CF423	Boolean Expression	
K6		
CF426	Mode	
CF427	Default State	
Digital Input		
D1		
CF501	Mode	
CF502	Normally Closed	

5. Digital Inputs

- To know LVD status, connect the auxiliary contact to the Digital Input 6. The ID CF526 is to select as “dc1_LvdState”




The below connection diagram is an example of LVD Auxiliary contact.



7.7 Manual Bypass Configuration

The manual by-pass is a manually operated switch, and it is used to transfer the load from normal to by-pass without interruption. When the system is in by-pass, the load is subjected to AC main disturbances. The standard manual by-pass is “Make before Break”. The MBP auxiliary contact must be connected to the Inview Digital input 1.

Go to [Advanced View](#) > [Site](#) > [Configuration](#) and scroll down to the Digital Input section. In the ID CF501, select the “convsl_ManualByPass” from the drop down list.




Note: For more information about MBP auxiliary connection with remote ON/OFF, refer to the system user manual.


7.8 Module Remote ON/OFF

The AC and DC output of the system and also each module in the system can be turned ON/OFF in two ways:

1. Remote ON/OFF terminal at rear side of the shelf or on a junction kit for Sierra XC parallelization: will impact only AC output.
2. Through web interface:
 - Systems Level
 - Both AC and DC: *Advanced View > Converter system > Control > System* section > CT41 and CT42
 - AC Only: *Advanced View > Converter system > Control > AC Outputs* section > CT101 and CT102
 - DC Only: *Advanced View > Converter system > Control > DC* section > CT511 and CT512



- Module Level
 - Both AC and DC: *Advanced View > Converter system > Converter > Control > Global* > CT11 and CT12
 - AC Only: *Advanced View > Converter system > Converter > Control > AC output* > CT21 and CT22
 - DC Only: *Advanced View > Converter system > Converter > Control > DC* > CT31 and CT32




7.9 Widgets Configuration

Widgets of different sorts are available. Up to 20 widgets can be configured on the home page. The configuration will appear both on the web interface and the LCD touch screens.

Perform the following step for Widgets configuration:

1. **Assigning number of widgets:** Go to *Advanced View > Energy System > Description > Connected Assets*. Click the edit icon and enter the number of assets connected to the system in the ID DE500. Click “Apply and Save” to apply changes.


For example, the Sierra System has four assets: AC Input, Battery, AC Load and DC Load. So, in the below screenshot, the number 4 is entered.



ID	NAME	VALUE
Global		
DE500	Number	4
Asset 1		
DE510	Type	Undefined
DE511	Name	Asset 1
Asset 2		
DE520	Type	Undefined
DE521	Name	Asset 2
Asset 3		
DE530	Type	Undefined
DE531	Name	Asset 3
Asset 4		
DE540	Type	Undefined
DE541	Name	Asset 4

Note: As soon as you start customizing your assets, the default one will be deleted, and you have to create all the assets you want to display. You can get the default assets back by setting DE500 to 0 again.

2. **Widget settings:** Go to Asset 1 in the ID DE510, select the type of widget and enter the desired name for the widget in ID DE511.




ID	NAME	VALUE
Global		
DE500	Number	4
Asset 1		
DE510	Type	Grid
DE511	Name	
Asset 2		
DE520	Type	
DE521	Name	
Asset 3		
DE530	Type	
DE531	Name	Asset 3

i) Similarly, configure for other remaining Assets.

S.No	Asset Name	Asset Type ID	Asset Name ID
1	Asset 1	DE510	DE511
2	Asset 2	DE520	DE521
3	Asset 3	DE530	DE531
4	Asset 4	DE540	DE541
N	Asset N	DE5N0	DE5N1


In the below screen shots, Assets 1, 2, 3 and 4 are assigned for AC Input, Battery, AC Loads and DC Loads, respectively.



The screenshot shows the Inview software interface. The 'Advanced View' toggle is turned on. The 'Description' tab is selected, showing a table of 'Connected Assets' with columns for ID, NAME, and VALUE. The assets are categorized by type: Global, AC Input, Battery, AC Loads, and DC Loads. Red boxes highlight the 'Description' tab and the 'Advanced View' toggle.

ID	NAME	VALUE
Global		
DE500	Number	4
AC Input		
DE510	Type	Grid
DE511	Name	AC Input
Battery		
DE520	Type	Battery
DE521	Name	Battery
AC Loads		
DE530	Type	AC Load
DE531	Name	AC Loads
DC Loads		
DE540	Type	DC Load
DE541	Name	DC Loads

ii) Toggle the Advanced view switch and verify all assigned widgets appear on the home page.




The screenshot shows the Inview software interface with the 'Advanced View' toggle turned off. The home page displays four widgets for AC Input, Battery, AC Loads, and DC Loads, all marked as 'Unconnected' with a power icon. An 'Alarms' section on the right lists four warnings: 'Connected Assets - AC Input Not connected to any equipment', 'Connected Assets - Battery Not connected to any equipment', 'Connected Assets - AC Loads Not connected to any equipment', and 'Connected Assets - DC Loads Not connected to any equipment'. Red boxes highlight the 'Advanced View' toggle and the 'Alarms' section.

In Widget settings, the type and name are assigned to the widget, which is not connected to the appropriate measurements. Follow the next step for connections.


3. **Widget Connections:** Each asset should be linked to a system node to get the real measurements. The different nodes possible with respect to the types are given in the following table. Choose the one that best matches your widget type among the possible links, depending on your system topology.

S.No	Widget	Type	Convention Type	Links to Measurements
1		Grid	Source	Converter System > Description > Asset Connections > DE502 (AC Input)
2		Genset	Source	Converter System > Description > Asset Connections > DE502 (AC Input)
3		DC Source	Source	Converter System > Description > Asset Connections > DE503 DC DC Converter System > Description > Asset Connections > <ul style="list-style-type: none"> • DE501 DC Internal • DE502 DC External
4		Solar	Source	Solar Power System > Description > Asset Connections > <ul style="list-style-type: none"> • DE501 (AC Outputs) • DE503 (DC)
5		Battery	Load	DC System > Description > Asset Connections > DE505 (Battery)
6		AC Load	Load	Converter System > Description > Asset Connections > <ul style="list-style-type: none"> • DE501 (AC Outputs) • DE502 (AC Inputs) Energy System* > Description > Asset Connections > DE501 (AC Outputs) *Shall be used for systems with PV inverter connected to the AC output. It considers the PV production in the computation of the load value.
7		DC Load	Load	DC System > Description > Asset Connections > DE504 DC Load

Go to *Advanced View > Converter System > Description > Asset Connections*.




- **AC Outputs:** In the ID DE501, Select the Asset name from the list connected to the system’s AC Output, like AC load or renewable sources. The “AC Loads” is selected in the screen shot above, which is the Asset name of the ID DE531. Refer to the screen shot on page 55.
- **AC Inputs:** In the ID DE502, Select the Asset name from the list connected to the system’s AC Input, such as Grid, Genset, Solar, Wind power, Hydro power, etc. The “AC Input” is selected in the screen shot above, which is the Asset name of the ID DE511. Refer to the screen shot on page 55.
- **DC:** In the ID DE503, Select the Asset name from the list connected to the system’s DC Input, such as Rectifier, MPT, etc. No DC input is connected to the system, so in the above screen shot, it is left blank.
- **DC Load and Battery:** Go to *Advanced View > DC System > Description > Asset Connections*.



- **DC Load:** In the ID DE504, Select the Asset name from the list connected to the system’s DC Output, like DC load. The “DC Loads” is selected in the screen shot above, which is the Asset name of the ID DE541. Refer to the screen shot on page 55.
- **Battery:** In ID DE505, Select the Asset name of the **Battery** from the list connected to System. The “Battery” is selected in the screen shot above, which is the Asset name of the ID DE521. Refer to the screen shot on page 55.

- Toggle the Advanced view switch and verify all assigned widgets are configured correctly on the home page.



7.10 Communication Protocol


7.10.1 Modbus

Modbus over TCP/IP is available, and it has both read and write mode, which means that Modbus can be used for monitoring and execute actions on the system. (Note: The write option is only available with the Operation license.)

Port is fixed to standard Modbus TCP/IP port 502. This protocol can be either enabled or disabled.

For the Modbus configuration, go to *Advanced View > Site > Configuration*, scroll down to the *Modbus* section and select the following options. It is also possible to filter on 'Modbus' - Use the filter button on the right.

In the ID CF155, select "True" to enable the Modbus TCP/IP function.



The following device/equipment mapping has been defined:

Device ID	Equipment
1	DC System 1
2	DC System 2
3	DC System 3
4	DC System 4
11	Inverter System 1
12	Inverter System 2

Device ID	Equipment
13	Inverter System 3
14	Inverter System 4
21	DC/DC Converter (Iris)
31	Converter System 1
32	Converter System 2
33	Converter System 3
34	Converter System 4
91	Energy System 1
100	Site
101	Sensors And Actuators 1
102	Sensors And Actuators 2

When the equipment does not exist, it will respond with function code 4:


- Each **discrete input** is associated with the alarm of the equipment, with the same id. Reading 1 means that the alarm is active.
- Each **input register** corresponds to the data of the equipment. All these values are coded assigned 16 bit. A correction factor is often applied. All the values are not available (like strings. Some status are coded as uint)
- Each **discrete coil** corresponds to the entries for controlling the equipment. It supports only simple control, without any parameters.
- Each **holding register** corresponds to the configuration of the equipment. It only supports entries that can be read and of numeric type. It includes advanced controls with parameters, complimentary with discrete coils.

The Modbus transport layer is Ethernet over TCP/IP. The default used port is 502:

- Discrete Inputs, alarm reading (Read Only), using modbus command 02.
- Input Registers, data reading (Read Only), using modbus command 04.
- Discrete Coils Table (Command), using modbus command 05.
- Holding registers, using modbus command 03 for multiple read, and 06 for a single write.

If you want to use Modbus to monitor other types of systems, please contact us. We will study the business case and make a proposal.

To download the Modbus data, log in to the Inview web interface, go to *Administration > Files > MMI References* and click the Modbus Map “**Export**” button.




7.10.2 SNMP

This section describes the Management Information Base (MIB) schema design for SNMP V1, V2c and V3 configuration. A MIB schema describes the structure of information served by a Simple Network Management Protocol Subsystem (SNMP) agent.

For the SNMP configuration, go to [Advanced View](#) > [Site](#) > [Configuration](#), scroll down to the *SNMP Agent* section and select the following options.

- In the ID CF61, select “True” to enable the SNMP function and enter the port address in the ID CF62.
- In the ID CF63, select the SNMP version V1, V2C or V3.




ID	NAME	VALUE
Global		
CF61	Enabled	True
CF62	Udp Port	161
CF63	Trap Version	V1
CF64	GET Minimum Security Level	V1 Community
CF65	SET Minimum Security Level	Not Allowed
CF77	Site Description Ids Included In Traps	-
CF611	Trap Targets IP	192.168.20.107
V3		
CF66	Authentication Algorithm	MD5

7.10.3 MIB

The MIB file describes the specific format of data provided by the SNMP agent running within the subsystem. The data is grouped in terms of high-level objects and therefore models a top-down hierarchical design.

To download the SNMP MIB file, go to [Administration](#) > [Files](#) > [MMI References](#) and click *SNMP MIB* “Export” button.




7.11 Cyber Security

7.11.1 Password Policy

Starting from Inview software version 5.5, a new password policy is introduced. The password must be a minimum of eight characters.

If the wrong password is entered continuously five times, next time, the Inview restrict to login, and it will allow again only after five minutes.



7.11.2 Weak Password Alarm

An alarm is raised when the system detects any user using a legacy password storage, default password or default pin code.



To fix the weak password alarm, check the followings:

- Ensure the PIN code is not having the default value.
- Ensure that no user is using the default password.
- If the configuration is migrated from an older version, use the web interface and change the existing password.

7.11.3 Password Protection

In Inview software version 5.5, a new password protection feature is added. To know more about it and configure it, go to [Advanced View > Site > Configuration > Webserver section > CF33 \(Enable password recovery\)](#).

- If “True” is selected, the web interface passwords and PIN details will be present while exporting the configuration and log files. *(Note: the password details are encrypted)*
- If “False” is selected, the password (for users, SNMP, Mail, MQTT, etc.) and PIN details are protected and will not be available in the configuration and log files.

7.11.4 Software Downgrade and Reset

To know about software downgrade and factory reset, go to [Advanced View > Site > Configuration > Controller section > CF152 and CF153](#). By default, the “True” option will be present on both parameters.

Maintenance		
CF152	Allow technical downgrade process	True
CF153	Allow technical Factory reset process	True


Warning: If both CF152 and 153 parameters are in False condition and the controller is corrupted, there is no possibility of recovering the data and cannot do the factory reset.

- **CF152 (Allow technical downgrade process):** Select the “True” option and downgrade the software version to the previous one using the USB key. Contact CE+T for the downgrading process.
- **CF153 (Allow technical Factory reset process):** Select the “True” option and perform the factory reset using USB Key. After the factory reset, the controller will be in default settings. Contact CE+T for the factory reset process.

8. Overview - LCD Interface

8.1 Inview Slot - LCD Display

Once the system is powered up, the Inview Slot is up and ready for operation. The LCD is a 1.8-inch touch screen and user can only view the system details through the interface.




- **[1] Interface area:** The interface area provides information about the corresponding page.
 - Displays the Site place, Date and Time.
 - The notification icon to view Alarms and Events and the settings icon provides access to other action screens.
 - Navigation arrows to the next screen or swipe left and right. Up and down arrows appear on some screens, indicating more information is present.
- **[2] Status bar**

The status bar appears throughout the interface and indicates the screen sequence.


8.1.1 LED Indications

Three LED's are present behind the front black plastic of the controller to indicate major alarm, minor alarm, and system status. These LED's are not visible until they illuminate during the corresponding action occurs.



8.1.2 Menu Structure


The home page is the default page in the LCD interface, and other pages are arranged in the below sequence.



8.2 Inview S - LCD Interface

Inview S LCD interface is a 2.8-inch touch screen. It does not have any user account, the user can only view the system details. The LCD interface is protected with the PIN during any action request. To modify the PIN, refer section 7.2.2, page 39.

Once system is powered upon, the Inview S is up and ready for operation.



- **[1] Header:** Displays the Site name, Date and Time.
 - **Events:** Tapping on  goes to Alarms and Events screen.
 - **Administration:** Tapping on  provide access to different action screens.
- **[2] Interface Area:** Tapping on the widget provides the corresponding parameter information.

Provides information about the corresponding screen. In some screens, left and right navigation buttons appear, indicating more screens are present.
- **Navigation arrows** for the next and previous pages. Up and down arrows appear on some screens, indicating more information is present.


8.2.1 LED Indications

Three LED's are present at front side of the controller to indicate major alarm, minor alarm, and system status.



8.2.2 Menu Structure


The below tree provides an overview of the menu structure in the Inview S LCD interface.



8.3 Inview X / X+ - LCD Interface

Inview X / X+ LCD interface is a 7-inch touch screen. Through the LCD interface, the user can view and access the system details. Once the system is powered upon, the Inview X / X+ is up and ready for operation.


Note: Interface graphics and layout may change based on firmware version.



- **[1] Header:** Displays the Site name, Date and Time.
 - **Events:** Tapping on  goes to Alarms and Events screen.
 - **Administration:** Tapping on  provide access to different action screens.
- **[2] Interface Area:** Tapping on the widget provides the corresponding parameter information. Provides information about the corresponding screen. In some screens, left and right navigation buttons appear, indicating more screens are present.
- **Navigation arrows** for the next and previous pages. Up and down arrows appear on some screens, indicating more information is present.

8.3.1 Menu Structure

The below tree provides an overview of the menu structure in the Inview X / X+ LCD interface.




8.3.2 LED Indications

Three LED's are present behind the front white plastic of the controller to indicate major alarm, minor alarm, and system status. These LED's are not visible until they illuminate during the corresponding action occurs.

Light Blue: Normal Operation

Orange: Minor Alarm

Red: Major Alarm



8.4 Inview XC - LED Indications

Three LED's are present at top side of the controller to indicate major alarm, minor alarm, and system status.



Red: Major Alarm

Orange: Minor Alarm

Green: System status (Normal Operation)

8.5 LCD Interface - Terminology

The below table provides the description of terminology which appears in Inview Slot, S, X and X+ LCD interface.

S.NO	Terminology	Description
1	Clean Inventory	The controller performs a complete scan and remove the non-active converters from the converter list. <i>Note: If any parameter is changed, an authentication page appears. Enter the display PIN password to apply changes. To modify the password, refer to section 7.2.2, page 39.</i>
2	Mute buzzer	Buzzer sound will be muted
3	Logs	Display the latest 100 events occurred
4	System Information	Displays product, network and software details

9. Defective Unit

9.1 Return Defective Inview

- A repair request should follow the regular logistics chain:
End-user => Distributor => CE+T Power.
- Before returning a defective product, a RMA number must be requested through the <http://my.cet-power.com> extranet. Repair registering guidelines may be requested by email at repair@cet.be
- **Freight costs:**
 - The cost to ship the unit(s) from the Customer's premises back to CE+T Power is at the Customer's charge.
 - CE+T Power will pay for the shipping of the unit(s) back to the Customer's premises.
- **Warranty:**
 - The warranty will be void if the transport conditions or packing were inadequate.
 - The warranty will be cancelled if the unit sent for repair has been opened by parties other than a CE+T approved Repair Centre.
- **Repair costs:**
 - If the faulty unit is under warranty, CE+T Power will bear the repair costs.
 - If the warranty is void, the repair costs will be invoiced to the Customer.
 - If a unit sent back to CE+T Power (Repair or Swap) presents no defect or failure, a lump sum amount will be charged to the Customer.
- **Swap conditions:**
 - You must provide CE+T Power with a Purchase Order for the new unit that you are requesting, at the current price. No Swap request will be accepted without it!
 - Within 3 months of the reception of our Swap approval email, you will have to provide CE+T Power with a tracking reference proving that you have shipped the faulty unit(s) back to CE+T Power.
 - If CE+T Power does not receive the tracking reference or the unit in time, CE+T Power will automatically invoice the unit(s) sent in exchange, at the current price list value.
- **RMA:**
 - Your Return Material Authorization number (RMA) and the address of the appropriate Repair Centre will be confirmed to you after careful review of your request.
 - The RMA number must be present on the packing and all the paperwork of the returned material.
 - So please, wait until you receive these two information before you ship us the faulty unit.

10. Trouble shooting and Service


For Service

- Check Service Level Agreement (SLA) of your vendor. Most of the time they provide assistance on call with integrated service. If such SLA is in place, you must call their assistance first.
- If your vendor doesn't provide such assistance (*) you may contact CE+T through email.
 - USA and Canada: tech.support@cetamerica.com
 - Rest of the world: customer.support@cet-power.com

Before sending the unit to repair, download the debug file and send it to CE+T customer support team through email.


Perform the following steps to download and send the file:

1. Go to **Administration > Support** and click **“Download support package”** to download the **“diagnostics”** zip file.




2. To send the diagnostic file to CE+T customer support, Click **“Request support”**, a new email will pop up from your default outlook with the CE+T address, subject and body text as below.

3. Attach the diagnostic file in the email and sent it.



11. Annexe 1: Converter - Parameter List

To view and edit the converter parameters, go to *Advanced View > Site > Energy System > Converter System > Configuration*.



The screenshot shows the Inview web interface. The top navigation bar includes 'Advanced View' (highlighted with a red box). The left sidebar shows a tree view with 'CONVERTER SYSTEM #1' selected (highlighted with a red box). The main content area displays a table of system parameters under the 'System' section.

ID	NAME	VALUE
CF1	Topology	UPS for AC loads
CF6	Number Of Phases	3
CF41	Enable Full Remote Control of Converters (Advanced)	True
CF1047	Triangle mode (Advanced)	0
CF1049	Start without supervision (Advanced)	1
CF1073	Lvd mode (Advanced)	0
CF1098	Sleep mode (Advanced)	0
CF1101	Enable Power Save Mode on DC (Advanced)	False
Phase 1		
CF121	Configured Converters	2
CF122	Redundant Converters	0
CF123	Nominal Phase Shift (Advanced)	0°
Phase 2		
CF141	Configured Converters	2
CF142	Redundant Converters	0
CF143	Nominal Phase Shift (Advanced)	120°

If you want to have an overview of standard systems' parameters, you can also view the parameters in our Monitoring Emulator <https://www.cet-power.com/en/monitoring-emulator/>. Do not hesitate to use the help buttons for more information about the parameters.

12. Annexe 2: PLC/Boolean Expression

12.1 Overview

PLC stands for Programmable Logic Controller. It allows adding custom features (data or alarms) by using some logical expression. It is very cost-effective for regulation where the main loop is not faster than one second.

Some configuration elements can be filled with a Boolean expression or a mathematical expression. In the following sections, you will find information about the syntax and some examples of valid expressions. PLC is only available with 'Operation' license.

A PLC Data is defined by any mathematical operation over any data.

A PLC Alarm is defined by any combination/operation of any information available in Inview. By default, a PLC alarm will have a severity level equal to 'none' so that it does not affect the system when it is incorrectly configured. For the alarm to pop up, it is needed to change the configuration of the alarm under 'Alarms'.

Boolean expressions can be used to open/close relays under user defined logics for their requirements and for specific alarm monitoring.

12.2 Abbreviations used in the Syntax

Abbreviations	Descriptions
esX	Refers to the Energy System with ID X
invsX	Refers to the Inverter System with ID X
convsX	Refers to the Converter System with ID X
dcdcX	Refers to the DC Converter System with ID X
rdcsx	Refers to the Remote DC System with ID X
dcX	Refers to the DC System with ID X
saX	Refers to the Sensors and Actuators with ID X
emX	Refers to the Energy Meter with ID X
spsX	Refers to the Solar Power System with ID X
invX	Refers to the Inverter with ID X
coX	Refers to the Converter with ID X
batX	Refers to the Battery with ID X
loadX	Refers to the (DC) Load with ID X
daX	Refers to Data with ID X
alX	Refers to Alarm with ID X
cfX	Refers to Configuration parameter with ID X
ctX	Refers to Control with ID X
deX	Refers to Description with ID X
severity_level	Refers to the highest severity level of the relative equipment (0->9)
severity_type	Refers to the highest severity type of the relative equipment (none - warning - minor - major - critical)

12.3 Use of syntax to access data entries from a monitored device

Syntax	Explanation
@(daXXX)	The data with ID XXX of the relative equipment (of the equipment where the PLC is written). Example: @(data501), @(da501)
@(esY_daXXX)	The data with ID XXX relative to the Energy System with ID Y. Example: @(es1_da100) – Denotes the active scheduling with ID DA100 from Energy System #1 (only available with some power management features)
@(spsY_daXXX)	The data with ID XXX relative to the Solar Power System with ID Y. Example: @(sps1_da11) – Denotes the data with ID DA11 from Solar Power System #1 (only available when the solar converter communicates correctly with Inview)
@(dcY_batZ_daXXX)	The data with ID XXX relative to the Battery with ID Z of the DC System with ID Y. Example: @(dc1_bat1_da5) – Denotes the voltage measurement data with ID DA5 from Battery #1 of DC System #1
@(dcdcY_coZ_daXXX)	The data with ID XXX relative to the Converter with ID Z of the DC Converter System with ID Y. Example: @(dcdc1_co1_da5) – Denotes the data with ID DA5 from Converter #1 of DC Converter System #1
@(convsY_coZ_daXXX)	The data with ID XXX relative to the Converter with ID Z of the Converter System with ID Y. Example: @(convs1_co1_da8) – Denotes the temperature measurement data with id DA8 from Converter #1 of Converter System #1
@(invsY_invZ_daXXX)	The data with ID XXX relative to the Inverter with ID Z of the Inverter System with ID Y. Example: @(invs1_inv1_da8) – Denotes the temperature measurement data with ID DA8 from Inverter #1 of Inverter System #1
@(emY_daXXX)	The data with ID XXX relative to the Energy Meter with ID Y. Example: @(em1_da10) – Denotes the current measurement data with ID DA10 from Energy Meter #1

Other possible syntaxes:

- @(dcY_daXXX), @(dcY_alXXX),...
- @(saY_daXXX), @(saY_alXXX),...
- @(invsY_daXXX), @(invsY_alXXX),...
- @(convsY_daXXX), @(convsY_alXXX),...
- @(spsY_daXXX), @(spsY_alXXX),...
- @(dcdcY_daXXX), @(dcdcY_alXXX),...
- ...

12.4 Use of syntax to access alarms grouped by severity level or severity type

@(severity_level)	The highest severity level active of the relative equipment (0->9). This can be useful to activate a relay based on the severity level.
@(severity_type)	The highest severity type active of the relative equipment (none - warning - minor - major - critical). This can be useful to activate a relay based on the severity level.
@(dcY_severity_level)	The highest severity level active, relative to the DC System with ID Y.
@(saY_severity_level)	The highest severity level active, relative to the equipment Sensors And Actuators with ID Y.


12.5 Operators & functions

Syntax	Explanation
(...)	Parentheses
&&	Logical AND
	Logical OR
= or ==	Equal
!=	Not Equal
+	Addition
-	Subtraction
*	Multiplication
/	Division
>	Superior
>=	Superior or Equal
<	Inferior
<=	Inferior or equal
\$second()	Second part of the actual time
\$minute()	Minute part of the actual time
\$hour()	Hour part of the actual time
\$day()	Integer indicating the day of the month
\$dayofweek()	Integer indicating the day of the week. This integer ranges from zero =>indicating Sunday, to six=> indicating Saturday
\$dayofyear()	Integer indicating the day of the year
\$month()	Integer indicating the month of the year
\$year()	Integer indicating the year
\$time()	The actual time of the day
@ts(XX:XX)	Create a timespan variable from XXXX string. Example: @ts(11:30) corresponds to 11:30.
\$iif(condition, val if true, val if false)	Equivalent to "If then else"
\$abs(XXX)	The absolute value of XXX
\$case(condition, val, condition2, val2, ...)	Equivalent to "switch"
\$ceil(XXX)	The ceil value of XXX
\$floor(XXX)	The floor value of XXX
\$max(X1, X2, X3, ...)	The maximum value between X1,X2,X3, etc.
\$min(X1, X2, X3, ...)	The minimum value between X1,X2,X3, etc.
\$sqrt(XXX)	The square root value of XXX

12.6 Examples of Boolean Expressions for custom PLC data, alarms and relays


12.6.1 Create a custom data

- a) Recalculate the voltage of the Converter System AC-out based on apparent power and current.
- l) Go to *Site > Configuration > PLC* to add a custom PLC data. (There is no PLC configuration possible under the Converter System)



ID	NAME	VALUE
CF901	Number Of Custom Data	0
CF902	Number Of Custom Alarm	0

- ii) Change the parameter CF901 (Number Of Custom Data) to '1'. You will see three new parameters (CF1301, CF1302 and CF1303).
- iii) Configure the data name, the mathematical expression and the unit.
 - Change the name CF1301 (e.g. "AC-out Voltage")
 - Change the Mathematical expression CF1302 to "@(convs1_da104)/@(convs1_da102)"
 - @(convs1_da104) represents the data with ID 104 of the Converter System: Global AC-output Apparent Power in this case.
 - @(convs1_da102) represents the data with ID 102 of the Converter System: Global AC-output Current in this case.
 - Change the unit CF1303 to 'V'.
- IV) The custom data is now available under *Site > Data > PLC*.




ID	NAME	VALUE
DA351	AC-out Voltage	230.00 V

12.6.2 Create a custom alarm

a) Adding an overload alarm on an energy meter.

i) Go to the concerned *Energy Meter* > *Configuration* > *PLC*.




ID	NAME	VALUE
CF601	Event Table Length	100
PLC		
Global		
CF901	Number Of Custom Data	0
CF902	Number Of Custom Alarm	0

ii) Change the parameter CF902 (Number Of Custom Alarm) of the energy meter to 1. You will see two new parameters (CF1001, CF1002).

iii) Configure the alarm name and triggering condition.

- Change the name CF1001 (e.g. "Overload current on line 1 (current > 1A)")
- Change the Boolean expression CF1002 to "@(da10) >= 1"
 - @(da10) represents the data with ID 10 of this device : Current – Phase 1 in this case.
 - '>=1' compares the data to a value superior or equal to 1.
- The alarm severity level is 'none' by default. The configuration of the alarm has to be changed under *Energy Meter* > *Alarms* > *PLC*. Adapt the severity level for the alarm to be shown.




ID	NAME	SEVERITY	RELAY	START TIME	STOP TIME	ACK TIME	ACKNOWLEDGE
AL1	Communication Failure	minor (4)	1	-	-	-	-
PLC							
Alarm 1							
AL10	Alarm 1	minor (4)	0	-	-	-	-

- Now, the alarm is triggered (pops up) when the data parameter with ID=10 (DA10) is superior or equal to one, when the current of phase 1 is higher than 1A.

b) Adding a high temperature alarm with a hysteresis.

- i) Go to *Site > Configuration > PLC* to add a custom PLC alarm.
(There is no PLC configuration possible under Sensors and Actuators (MBB 60V and MBB 500V) on which your temperature sensor is cabled.)



ID	NAME	VALUE
CF901	Number Of Custom Data	0
CF902	Number Of Custom Alarm	0


- ii) Change the parameter CF902 (Number Of Custom Alarm) to 1. You will see two new parameters (CF1001, CF1002).

- iii) Configure the alarm name and triggering condition.

- Change the name CF1001 (e.g. “Indoor Temperature High”)
- Change the Boolean expression CF1002 to
`"(@sa1_da301)>50 || ((@al101) == True && @(sa1_da301) > 48)"`
 - The alarm will be triggered if @sa1_da301 - the temperature DA301 of the Sensors and Actuators #1 - is over 50°C OR if @alarm101 – current alarm - is true and @(data1) is still over 48°C.
 - The alarm severity level is 'none' by default. The configuration of the alarm has to be changed under *Site / Alarms / PLC*. Adapt the severity level for the alarm to be shown.

c) Adding an alarm for the battery being in 'Charge' state.

- i) Go to *DC System > Configuration > PLC* to add a custom PLC alarm.



ID	NAME	VALUE
CF901	Number Of Custom Data	0
CF902	Number Of Custom Alarm	0


- II) Change the parameter CF902 (Number Of Custom Alarm) to 1. You will see two new parameters (CF1001, CF1002).
- III) Configure the alarm name and triggering condition.
 - Change the name CF1001 (e.g. "Battery in Charge")
 - Change the Boolean expression CF1002 to "@(da1)=2"
 - The alarm will be triggered if @(da1) - the Battery state DA1 of the DC System - is equal to 2.
 - The possible values of DA1 are:
 - 0 = Unknown
 - 1 = Disconnected
 - 2 = Charge
 - 3 = Discharge
 - 4 = Warning
 - 5 = Error
 - The alarm severity level is 'none' by default. The configuration of the alarm has to be changed under [DC System > Alarms > PLC](#). Adapt the severity level for the alarm to be shown.

12.6.3 Create a custom relay

a) Based on a mathematical expression: Relay for starting and stopping of a genset based on the Voltage of the Battery.

The easiest way to do this is by creating an alarm and assigning the alarm to a relay.

- I) Go to [DC System > Configuration > PLC](#) to add a custom PLC alarm.




The screenshot shows the configuration interface for the DC System. The 'Configuration' tab is active, and the 'PLC' section is expanded. The 'Global' parameters are visible:

ID	NAME	VALUE
CF401	Number of Loads	0
CF601	Event Table Length	100
CF901	Number Of Custom Data	0
CF902	Number Of Custom Alarm	0

- II) Change the parameter CF902 (Number of Custom Alarm) to 1. You will see two new parameters (CF1001, CF1002).


III) Configure the alarm name and triggering condition.

- Change the name CF1001 (e.g. "Start Genset")
- Change the Boolean expression CF1002 to " $(@(\text{da60}) \leq 47) \parallel (@(\text{al601}) \& \& @(\text{da60}) \leq (@(\text{da18}) - 0.1) \& \& (@(\text{da61}) < -1 \parallel @(\text{da61}) > @(\text{da19}) / 10))$ ".
 - The alarm will be triggered if @(\text{da60}) - the Battery voltage DA60 of the DC System - is less than 47V OR if the alarm is already active (@(\text{al601})) and the Battery voltage DA60 is less than the target voltage -0.1V (@(\text{da60}) ≤ (@(\text{da18}) - 0.1)) and the measured current is less than -1A (@(\text{da61}) < -1) or the measured current is above 10% of the maximum charging current limit (@(\text{da61}) > @(\text{da19}) / 10).
- The alarm severity level is 'none' by default. The configuration of the alarm has to be changed under *DC System > Alarms > PLC*. Adapt the severity level for the alarm to be shown. Assign the alarm AL601 to the virtual relay 1.



ID	NAME	SEVERITY	SEVERITY LEVEL	RELAY	SET DELAY	CLEAR DELAY
AL401	Disconnected	minor	4	0	5	2
AL402	Saturated	minor	4	0	5	2
AL601	Start Genset	none	0	1	5	2

IV) Go to *Site > Configuration > Relay* if the relay is on Inview, go to *Sensors and Actuators > Configuration > Relay* if the relay is on an MBB. Set the mode of the corresponding relay to 'GlobalRelay(1)'.




ID	NAME	VALUE
CF401	Mode	GlobalRelay(1)
CF402	Default State	De-energized
CF406	Mode	-
CF407	Default State	De-energized

ID	NAME	VALUE
CF501	Mode	Custom
CF502	Normally Closed	False

b) Based on a custom expression.

- i) Go to *Site > Configuration > Relay* if the relay is on Inview, go to *Sensors and Actuators > Configuration > Relay* if the relay is on an MBB. Set the mode of the corresponding relay to 'Custom'.
- ii) Change the Boolean expression to the desired condition.




ID	NAME	VALUE
CF401	Mode ?	Custom
CF402	Default State ?	De-energized
CF403	Boolean Expression	@(dc1_da60)<=47
CF406	Mode ?	-
CF407	Default State ?	De-energized

ID	NAME	VALUE
CF501	Mode ?	Custom

c) Based on severity level

- i) Go to *Site > Configuration > Relay* if the relay is on Inview, go to *Sensors and Actuators > Configuration > Relay* if the relay is on an MBB. Set the mode of the corresponding relay to 'Custom'.
- ii) Change the Boolean expression to the something like “@(dc1_severity_level)>=2”.




ID	NAME	VALUE
CF401	Mode ?	Custom
CF402	Default State ?	De-energized
CF403	Boolean Expression	@(dc1_severity_level)>=2
CF406	Mode ?	-
CF407	Default State ?	De-energized

ID	NAME	VALUE
CF501	Mode ?	Custom

- @(dc1_severity_level) correspond to the highest severity level active among the alarms of DC System #1.
- Pay attention that @(dc1_severity_level)=2 will not Energize the relay if there are both alarms with a severity level of 2 and alarms with higher severity levels that are active in the DC System #1. All elements under DC System #1 are considered to determine the highest severity level.

d) Based on severity type.

- i) Go to *Site > Configuration > Relay* if the relay is on Inview, go to *Sensors and Actuators > Configuration > Relay* if the relay is on an MBB. Set the mode of the corresponding relay to 'Custom'.
- ii) Change the Boolean expression to the something like "@(dc1_severity_type)>="major"".



- @(dc1_severity_type) correspond to the highest severity type active among all alarms of DC System #1.
- Pay attention that @(dc1_severity_type)="minor" will not Energize the relay if there are both alarms with a severity type of "minor" and alarms with higher severity types that are active in the DC System #1. All elements under DC System #1 are considered to determine the highest severity type.


12.6.4 Simple examples of custom alarms or data

Condition or Data	Configuration examples
The bus voltage is under 47V.	@(data11)<47
If the specific inverter output power is over 2500W	@(conv1_co1_data13)>2500
The time of the day is comprised between 10:30 and 11:30	(\$time())>@ts(10:30)&&(\$time())<@ts(11:30)
The day of the week is Sunday	\$dayofweek()==0
The alarm with ID 17 is active	@(alarm17) ==True
The alarm with ID 17 and 18 are active	@(alarm17) ==True && @(alarm18) ==True
Linking Digital input with relay	<ul style="list-style-type: none"> • If Digital input 3 is closed then relay K3 need to be energized. <ul style="list-style-type: none"> ▪ D3 alarm ID from Inview: al511 ▪ Boolean expression set at relay : @(sa1_al511) • Mode: Custom; Boolean Expression: @(sa1_al511)

Condition or Data	Configuration examples
Linking Specific alarm with Relay	<ul style="list-style-type: none"> • If Redundancy lost alarm need to be configured with relay <ul style="list-style-type: none"> ▪ Redundancy lost alarm ID from Inview: al103 ▪ Boolean expression need to be set at relay: @ (convs1_al103) • Mode: Custom; Boolean Expression: @(convs1_al103)
Linking Specific data with Relay	<ul style="list-style-type: none"> • When the battery voltage reaches below 45V <ul style="list-style-type: none"> ▪ Battery voltage measurement displayed at: sensors and actuators > Data> da101 ▪ Boolean expression need to be set at relay: @(sa1_al101)<45 • Relay Mode: Custom; Boolean Expression: @(sa1_da101)<45

13. Annexe 3: Inview - Software Upgrade

The current software version number is present on [User Context > About](#). To know more about software details, go to [Advanced View > Site > Description](#) and scroll down to the Controller section.




The screenshot shows the Inview web interface. The 'Advanced View' toggle is active. The left sidebar shows a tree view with 'SITE #1' selected. The main content area is titled 'Controller' and contains a table with the following data:

ID	NAME	VALUE
Software		
DE90	Running Compas Informational Version	Inview Compas 6.1.0-3+1638
DE91	Running Compas Version	6.1.0.3
DE92	Platform Version	6.1.0+2467
DE105	Factory Compas Version	6.1.0.3
DE106	User Compas Version	-
Hardware		
DE93	CPU	IMX6-Inview
DE94	Platform	Inview S
DE95	Part Number	T602004100
DE96	Serial Number	000849


Perform the following steps to upgrade Inview software, and this process can do only through the web interface.

1. Go to my.cet-power.com > Documents > Download SOFT > 2_MONITORING (link) and download the latest software from the 5_INVIEW_X.0 folder. The downloaded file will be “.RAR”, extract and save it in local as “.UPG” extension.




The screenshot shows the website interface. The 'Documents' menu is open, and the 'Download SOFT' option is highlighted. The '5_INVIEW_5.0' folder is also highlighted in the file list.

2. Login as admin privileged account in the Inview web interface and go to *Administration > Software Update*.



3. Click “Choose file” button and direct to the downloaded .UPG file and the Click “Upload, save configuration and reboot” button.



4. Wait, the upgrading process will take approximately 15 minutes to return to normal operating conditions.
5. After successful up-gradation, the web interface resumes to the login screen. Login and verify the Software version below the Inview logo or go to the *Controller* section at *Advanced View > Site > Description* page.

Note: During the upgrade, it is highly recommended to ensure that the Inview does not get shut down (it might get bricked). Therefore, it is recommended to use a redundant power supply.

14. Annexe 4: Hardware Replacement


14.1 Inview Slot, S, X, X+ and XC

Before replacing the new Inview Slot, S, X, X+ or XC, the existing configuration file must be saved and need to upload the same after installing the new controller.


Perform the following steps for replacing Inview Slot, S, X, X+ or XC:

1. Login as admin privileged account, go to *Administration > Configuration*, click “Download configuration file” button, and save the file in local.

Note: The downloaded file name will be as “configuration.xml” and it should not be renamed.




2. Remove the existing controller and install the new controller. To know about installing it and its hardware connections, refer to the section 5, page 20.
3. Power on the controller and login as admin privileged account.
4. Go to *Administration > Configuration*, click “Choose file” button, and direct to the downloaded “configuration.xml” file. Then click “Upload configuration and reboot” button.



14.2 Accessories - MBB 60V / MBB 500V


Perform the following steps for replacing MBB 60V / MBB 500V:

1. Remove the existing MBB from the system.
2. Clear from the inventory list: go to *Advanced View > Site > Control*, scroll down to the *Inventory* section. In the ID CT61 (Clean Equipment Inventory), click the  icon to clear it from the list.



ID	NAME	EXECUTE
General		
CT60	Save ?	
CT61	Clean Equipment Inventory ?	
CAN Bus		
CT81	Reset CAN Bus Node ?	1 
CT82	Save CANOpen LSS Configuration	


3. Connect the new MBB in the system. To know about the hardware connections, refer to the section 5.6, page 23.
4. Once the MBB is powered on, make sure it was detected and listed in the “Sensors and Actuators” list.
5. Go to *Advanced View > Sensors and Actuators*, scroll down to *Relay* and *Digital Input* section, and verify the mappings are done correctly.



ID	NAME	VALUE
K1		
CF401	Mode ?	Custom
CF402	Default State ?	De-energized
CF403	Boolean Expression	False
K2		
CF406	Mode ?	Custom
CF407	Default State ?	De-energized
CF408	Boolean Expression	@(convs1_co1_al4)
K3		
CF411	Mode ?	Custom
CF412	Default State ?	De-energized
CF413	Boolean Expression	@(dc1_al51)
Digital Input		
D1		
CF501	Mode ?	Custom
CF502	Normally Closed ?	False
D2		


15. Annexe 5: Wiring Diagrams

15.1 Inview Slot with MBB



Note: The schematic corresponds to MBB 60V; it is similar for MBB 500V except that V3, I3, K5 and K6 do not exist on MBB 500V.


15.2 Inview S with MBB



REMARKS : X9 1-2 CLOSE IN CASE OF MAJOR ALARM
X9 4-5 CLOSE IN CASE OF MINOR ALARM


Note: The schematic corresponds to MBB 60V; it is similar for MBB 500V except that V3, I3, K5 and K6 do not exist on MBB 500V.

15.3 Inview X / X+ with MBB



Note: The schematic corresponds to MBB 60V; it is similar for MBB 500V except that V3, I3, K5 and K6 do not exist on MBB 500V.


15.4 Inview XC with MBB



16. Annexe 6: Auxiliary power supply kit

16.1 Auxiliary power supply kit with Din Rail


S.No	Model	Part number
1	48 Vdc	T602004122
2	110 Vdc	T602004124
3	380 Vdc	T602004123



- X10 - AC input terminal (1P)
- X11 - DC input terminal (Battery voltage)
- X12 - DC Output terminal (12 V DC)
- X13 - Alarm contact for Aux power supply unit fail
- X14 - Diodes


Front View

16.2 Auxiliary power supply kit - Wiring diagram




17. Annexe 7: Inview Panel Sheets


17.1 Inview S - Panel Sheets



3U Panel sheet - cut out details




2U Panel sheet (center)- cut out details




2U Panel sheet (left)- cut out details

17.2 Inview X / X+ - Panel Sheet



17.3 Inview XC - Dimensions



Disclaimer

USA:

Federal Communications Commission (FCC) Statement 15.105(b)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure

1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
2. For portable operation, this device has been tested and meets FCC RF exposure guidelines. When used with an accessory that contains metal may not ensure compliance with FCC RF exposure guidelines.

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

Canada:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. l'appareil ne doit pas produire de brouillage, et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Caution: Exposure to Radio Frequency Radiation

1. To comply with the Canadian RF exposure compliance requirements, this device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.
2. For portable operation, this device has been tested and meets RF exposure guidelines when used with an accessory that contains no metal. Use of other accessories may not ensure compliance with RF exposure guidelines.

Attention: exposition au rayonnement radiofréquence

Pour se conformer aux exigences de conformité RF canadienne l'exposition, cet appareil et son antenne ne doivent pas être co-localisés ou fonctionnant en conjonction avec une autre antenne ou transmetteur.

Pour portable utilisation, cet appareil a été testé et respecte les directives sur l'exposition aux RF lorsqu'il est utilisé avec un accessoire sans métal. L'utilisation d'autres accessoires peut ne pas garantir la conformité aux directives d'exposition aux RF.

To comply with the Canadian RF exposure compliance requirements, this device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

For portable operation, this device has been tested and meets RF exposure guidelines when used with an accessory that contains no metal. Use of other accessories may not ensure compliance with RF exposure guidelines.

